# HONDA EM6000GN

# **1. SPECIFICATIONS**

1. SPECIFICATI 2. PERFORMAI	ONS NCE CURVE	3. WIRING DIAGRAM			
1. SPECIFICATI	ONS	Spola, revolution and compare and compare and compare and revolution of the second second and the second se			
DIMENSIONS A	ND WEIGHTS	Exclision method			
	NALE VORAGE REGULATOR	Unit: mm (in)			
Itom	Model	EZCM			
Overall length	Description code	220 (22 7)			
Overall width	AV 000 VA	510 (20.1) *655 (25.8)			
Overall height	220 V	490 (19.3) *565 (22.2)			
Dry weight		79.0 kg (174.2 lbs) *84.5 kg (186.3 lbs)			
Operating weight		93.0 kg (205.0 lbs) *98.5 kg (217.2 lbs)			
With 4 wheels kit.		Powar factor (Cop a)			
ENGINE					
Туре	5 566, 718 V	GX390 K1: 4-stroke, overhead valve single cylinder, inclined by 25°			
Total displacement	21 E MAN 97	389 cm <sup>3</sup> (23.7 cu in)			
Bore x Stroke	15% max.	88 x 64 mm (3.5 x 2.5 in)			
Maximum horsepov	wer	6.3 kW (8.5 PS) at 3,600 min <sup>-1</sup> (rpm)			
Maximum torque	5 \$\$C. max	0 20 amp agaravia			
Compression ratio	Set Fundament	8.0 : 1 your all your			
Fuel consumption	10-MD min.	0.42 Nm³/kWh (0.31 Nm³/PSh)			
Cooling system	A 0.81	Forced air			
Ignition system		Transistorized magneto ignition			
Ignition timing	XWh (0.31 Nm?/PSh)	30° B.T.D.C. (Fixed)			
Spark plug	3 (A) at 7 m (23 ft)	BPR6ES (NGK)			
Carburetor		Horizontal type, butterfly valve			
Air cleaner		Semi-dry type			
Governor		Centrifugal			
Lubricating system		Splash type			
Oil capacity		1.1ℓ (1.16 US qt, 0.97 Imp qt)			
Starting system		Electric starter			
Stopping system		Primary circuit ground			
Recommended fuel		Natural gas (8,800 ± 200 kcal/Nm <sup>3</sup> )			
Supply pressure		200 ± 50 mm H <sub>2</sub> O (8 ± 2 inch W.C.)			
Recommended	Inside diameter	13 mm (0.5 in)			
gas hose	Length	6 m (19.7 ft) or below			
Recommended oil		SAE 10W – 30 SG minimum			
P.T.O rotational direction		Counterclockwise (viewed from the generator)			

# 1. SPECIFICATIONS

# HONDA EM6000GN

GENERATOR		SPECIFICATIONS
	Model	EM6000GN AUD SOMAMACOMAS
Item	Туре	R
Generator type		2-pole, revolving magnetic field type
Generator structure	9	Self-ventilation, drip-proof type
Excitation method		Self-excitation
Voltage regulation	system	AVR (Automatic Voltage Regulator)
Phase	MEDDIGN	Single phase
Rotating direction	MOST	Counterclockwise (Viewed from the generator)
Maximum output	830 (32.7)	4,500 VA
Rated output	610 (20.1)	4,000 VA
Rated frequency	665 (25.8)	50 Hz
Rated voltage	490 (19.3)	220 V
Rated current	005 (22.2)	18.2 A
DC output		(1. Shier)
DC voltage	100 100 100 100 100 100 100 100 100 100	(1.22-m)
DC current	kg (217.2.16a)	1.801 mm In All in Land Land Land
Power factor (Cos ø	ð)	1.0 a siderby \$ div/
Voltage variation	Momentary	15% max.
rate	Average	7% max.
	Average time	3 sec. max.
Voltage stability	A Valence .	Within ± 1%
Frequency	Momentary	15% max.
variation rate	Average	7% max.
	Average time	5 sec. max.
Frequency stability	T OR	Within ± 1%
Insulation resistance		10 MΩ min.
Circuit breaker	lis bisson 1	19.0 A
DC circuit protecto	noltinol openet no	Instainen Iveten
Fuel consumption	(at rated load)	0.42 Nm <sup>3</sup> /kWh (0.31 Nm <sup>3</sup> /PSh)
Noise level	NON RAFS (NGK)	72 dB (A) at 7 m (23 ft)

	feed for maximum rear	



## HONDA EM6000GN

# 2. SERVICE INFORMATION

#### **1. GENERAL SAFETY**

#### 3. TROUBLESHOOTING

2. MAINTENANCE STANDARDS

#### 4. MAINTENANCE SCHEDULE

A CARLON AND A

**1. GENERAL SAFETY** 

Pay attention to these symbols and their meanings:

A WARNING Indicates a strong possibility of severe personal injury or death if instructions are not followed.

CAUTION: Indicates a possibility of personal injury or equipment damage if instructions are not followed.

#### A WARNING

- Stop the engine, and remove the spark plug cap and ignition key before servicing.
- If the engine must be running to do some work, make sure the area is well ventilated. Never run the engine in a closed area; the exhaust contains poisonous carbon monoxide gas.
- Natural gas is extremely flammable and is explosive under certain conditions. Check for leaks regularly by using detergent solution or trace by smell.
- Do not smoke or allow flames or sparks in your working area.

#### CAUTION:

- Keep away from rotating or hot parts and high voltage wires when the engine is running.
- Take care not to drop the bolts, etc. fall between the flywheel and cylinder barrel. Do not bend the governor link.

#### 2. MAINTENANCE STANDARDS Part Standard Service limit Item 0.8 - 1.0 Ω Main winding Resistance **Field winding** Resistance $55 - 65 \Omega$ Exciter winding Resistance $1.0 - 1.2 \Omega$ **Brush length** 9 mm (0.4 in) Carbon brush 5 mm (0.2 in)



(\* 1) Have an authorized Honda gas Generator check and adjust the system/appliance.

# HONDA **3. TROUBLESHOOTING** a. ENGINE

EM6000GN

· Use a fully charged 12 V battery.



(\*1): Have an authorized Honda gas Generator check and adjust the system/appliance.



(\*1): Have an authorized Honda gas Generator check and adjust the system/appliance.



(\*1): Have an authorized Honda gas Generator check and adjust the system/appliance.

Have dy approximate Monica gas Ganerator check and adjust the systemic measure.

#### b. OIL ALERT SYSTEM

HONDA EM6000GN

Engine does not stop when the engine oil is insufficie

NOTE: Never start the engine when the oil has been drained. Engine does not start with combination switch ON. • Check oil level before proceeding. Add the recommended engine oil if necessary. No spark See IGNITION SYSTEM troubleshooting (P. 2-7). 1. Disconnect the black wire of the oil alert unit. Perform spark test [P. 2-9 of base shop manual (62ZP000)]. **OIL ALERT UNIT BLACK WIRE** Sparks Sparks 2. Reconnect the black wire and disconnect Faulty oil level switch. · Replace the oil level switch [P. 12-1 of base the yellow wire of the oil level switch. Perform spark test [P. 2-9 of base shop shop manual (62ZP000)]. manual (62ZP000)]. **YELLOW WIRES** No spark Faulty oil alert unit. · Replace the oil alert unit.



# HONDA EM6000GN

# 5. FUEL SYSTEM

PROVIDENTIAL ADDRESS A			NO STRUCTURE OF MAL	SSGALEWSISSISS
IGNITION SY	STEM			
Engine does u	not start with combination	switch ON		
Lingine does i	First Every 3 Every 6 Eve	switch ore.		
1 D (				
1. Perform spa manual (627P	rk test [P.2-9 of base shop			
mandar (0221				
	No spark			
	NO Spark			
2 Check again	after replacing with a pow	Sparks	- Equity apark plug	
spark plug.	after replacing with a new		Replace the spark plug.	nula haai
-46			Chapped (Chapped	<u>809 04, 8 1908</u>
	No spark			
	eleant cash 11:5-2 of balanting-			
3 Disconnect th	e black wire from the combi-	Sparks	Eaulty combination swite	ch
nation switch	and retest.		Replace the combination	on switch (P.6-1).
			Faulty oil alert system.	
	No spark		• See OIL ALERT SYST	EM troubleshootin
				<u>Sanaga muse (negles</u>

## HONDA EM6000GN

#### c. INSPECTION

#### SOLENOID VALVE

1) Using an ohmmeter, measure the resistance between the terminals.

	Resistance	26.1 – 31.9 Ω
1.8		



 Connect the 12 V battery to the solenoid valve terminals and be sure that the valve operates.



d. REASSEMBLY

 Remove the sealing tape or liquid packing thoroughly from the threaded parts of the pipe, joint, bushing, nipple and the valve.

#### CAUTION:

Check inside of each part for the sealing tape or liquid packing. Remove even small pieces of the sealing tape or liquid packing if they remain inside the parts.

2) Wind the sealing tape 1-1/2 turns around the threaded parts of the joints, bushing and the nipple, and apply the liquid packing (HERME SEAL G-2 or equivalent) to the threads.

#### NOTE:

• Do not attach the sealing tape to the very end of the threaded part but leave one or two threads from the end untaped. Wind the tape 1-1/2 turns around the threads.

 Apply the liquid packing (HERME SEAL G-2 or equivalent) thoroughly around the threads of the part that is from the thread end to the second thread.





# 2. INSPECTION

#### VALVE CONTROL UNIT

- Remove the control box, but do not disconnect the harnesses that come from the control box this time. Open the control box.
- Attach one tester lead to the white/yellow terminal and the other lead to the black terminal of the control unit 4P connector.
- 3) Turn the combination switch OFF and turn it ON again. There must be 12 V of the DC voltage between the white/yellow terminal and black terminal of the control unit 4P connector for  $4 \pm 2$  seconds.
- 4) If the specified voltage is not available for  $4 \pm 2$  seconds, replace the valve control unit.
- 5) If the specified voltage is available for  $4 \pm 2$  seconds, proceed to the following step.
- 6) Turn the combination switch OFF once, then start the engine.
- Check whether there is 12 V of the DC voltage between the white/yellow terminal and black terminal of the control unit 4P connector.
- 8) If the specified DC voltage is not available between the terminals, replace the valve control unit.
- If the specified DC voltage is available, proceed to the following procedure.



HONDA EM6000GN

- 10) Attach one tester lead to the white/yellow terminal and the other tester lead to the black terminal of the valve control unit 4P connector.
- 11) Stop the engine.
- 12) Measure the voltage between the white/yellow and black terminals of the 4P connector within 0.5 seconds after the engine stop. It must be 0 V.
- 13) If the measurement is not 0 V, replace the valve control unit.
- 14) If the measurement is 0 V, proceed to the following procedure.



## HONDA EM6000GN

# A

- 15) Start the engine again.
- 16) Attach one tester lead to the white/yellow terminal and the other tester lead to the black terminal of the valve control unit 4P connector.
- 17) Disconnect the yellow connector from the oil alert unit and attach it to the engine to ground. Be sure that the engine stops.
- 18) Measure the voltage between the white/yellow and black terminals of the 4P connector within 0.5 seconds after the engine stop. It must be 0 V.
- 19) If the engine does not stop, check the oil alert unit. Replace the oil alert unit if necessary.
- 20) If the measured voltage is not 0 V within 0.5 seconds after the engine stop, replace the valve control unit.
- 21) The valve control unit is normal if the above procedures checked out all right.



#### HOUR METER

#### TERMIN

 Check for continuity between the terminals of the hour meter 2P connector. There should be continuity.



- Connect the 12 V battery voltage between the white/yellow and yellow/green terminals of the hour meter 2P connector. The hour meter must start within 8 seconds.
- 3) The hour meter is normal if the step 1 and 2 checked out all right.



# HOND?

#### VOLT METER

Output voltage is normal but volt meter needle does not swing:

Start the engine and check whether there is voltage at the volt meter terminal.

Rated voltage	220 V

If there is no specified voltage at the terminal, replace the volt meter.



#### REGULATOR

Measure the resistance between the connectors. Replace the regulator if the measurement is out of the specified range shown in the table below.

1 Init.	0
Unit.	77

TESTER (+) TESTER (-)	Red	Blue	Blue	Green
Red		8	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	∞
Blue	∞		∞	50 k - 199.9 k
Blue	∞	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		50 k - 199.9 k
Green	50 k - 199.9 k	00	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	



#### SILICON RECTIFIER

Check for continuity between the terminals. Attach the positive (+) tester lead to the terminal A of the silicon rectifier and attach the negative (–) tester lead to the terminal B.

There must be continuity (in the normal direction).

Attach the negative (-) tester lead to the terminal A and the positive (+) tester lead to the terminal B. There must be no continuity.



Connect the 12 V pattery voltage between the white/yellow and yellow/greate terminals of the hour meter 2P connector. The hour patter mind start within 8 seconds.

The hour meter is recided (10h stap 1 and 2 checked

BLACK

# 4. MAINTENANCE STANDARDS

## • ENGINE

	-100	S.O EPE	5000	SON SIZE FPA	500S
Part	Item	Standard	Service limit	Standard	Service limit
Engine	Maximum speed 50 Hz	2 150 ± 150 min-1 (rpm)		2 150 ± 150 min-1 (mm)	
Lingine	60 Hz	$3,150 \pm 150 \text{ min}^{-1} \text{ (rpm)}$		$3,150 \pm 150 \text{ min}^{-1} \text{ (rpm)}$ $3.750 \pm 150 \text{ min}^{-1} \text{ (rpm)}$	
	Cylinder compression	6.0 - 8.5 kg/cm <sup>2</sup>	N. I	6.0 - 8.5 kg/cm <sup>2</sup>	22
		(85 – 121 psi)	and a share	(85 – 121 psi)	
A	111.0-	at 600 min <sup>-1</sup> (rpm)		at 600 min <sup>-1</sup> (rpm)	00.47
Cylinder	Sleeve I.D.	82.00 mm (3.228 in)	82.17 mm (3.235 in)	88.00 mm (3.465 in)	88.17 mm (3.471 in)
Cylinder head	Warpage	THE REAL PROPERTY AND A DESCRIPTION OF A	0.10 mm (0.004 in)		0.10 mm (0.004 in)
Piston	Skirt O.D.	81.985 mm (3.2277 in)	81.85 mm (3.222 in)	87.985 mm (3.4640 in)	87.85 mm (3.459 in)
	Piston-to-cylinder	0.015 - 0.052  mm	0.12 mm (0.005 in)	0.015 - 0.052  mm	0.12 mm (0.005 ip)
	Piston pin bore I.D.	20.002 mm (0.7875 in)	20.042 mm (0.7891 in)	20.002 mm (0.7875 in)	20.042 mm (0.7891 in)
	Pin O.D.	20.00 mm (0.787 in)	19.95 mm (0.785 in)	20.00 mm (0.787 in)	19.95 mm (0.785 in)
	Piston-to-piston pin	0.002 – 0.014 mm	0.08 mm	0.002 – 0.014 mm	0.08 mm
NOT STREET	bore clearance	(0.0001 – 0.0006 in)	(0.003 in)	(0.0001 – 0.0006 in)	(0.003 in)
Piston rings	Ring side clearance:	0.030 – 0.060 mm	0.15 mm	0.030 – 0.060 mm	0.15 mm
	Top/second	(0.0012 - 0.0024 in)	(0.006 in)	(0.0012 - 0.0024 in)	(0.006 in)
	Ring end gap:	0.2 – 0.4 mm	1.0 mm	0.2 – 0.4 mm	1.0 mm
	l op/second	(0.01 – 0.02 in)	(0.04 in)	(0.01 – 0.02 in)	(0.04 in)
		(0.01 - 0.02  in)	1.0 mm	0.2 - 0.7  mm	(0.04 ip)
	Bing width: Top/second	(0.01 - 0.03  mm)	1 75 mm (0.069 in)	2.0  mm (0.08  in)	1 75 mm (0.069 in)
Connection	Small and LD	20.005 mm (0.7076 in)	20.07 mm (0.000 in)	20.005 mm (0.7076 in)	20.07 mm (0.000 in)
connecting	Big and LD.	20.005 mm (0.7876 m)	20.07 mm (0.790 in)	20.005 mm (0.7876 m) 26.025 mm (1.4182 in)	20.07 mm (0.790 m)
100	Big end oil clearance	0.040 = 0.066  mm	0.12 mm	0.040 - 0.066  mm	0.12 mm
	Dig chu ch cicarance	(0.0016 - 0.0026  in)	(0.005 in)	(0.0016 - 0.0026  in)	(0.005 in)
	Big end side clearance	0.1 – 0.7 mm	1.0 mm	0.1 – 0.7 mm	1.0 mm
	-1.3 Ω	(0.004 – 0.028 in)	(0.04 in)	(0.004 - 0.028 in)	(0.04 in)
Crankshaft	Crankshaft O.D.	35.985 mm (1.4167 in)	35.93 mm (1.415 in)	35.985 mm (1.4167 in)	35.93 mm (1.415 in)
Valves	Valve clearance IN	0.15 ± 0.02 mm		0.15 ± 0.02 mm	
	1.10	(0.006 ± 0.001 in)	IVI J	(0.006 ± 0.001 in)	37
	EX	0.20 ± 0.02 mm		0.20 ± 0.02 mm	
	Ω.6.0	(0.008 ± 0.001 in)	P5000 P 7/1	(0.008 ± 0.001 in)	Burdue An
	Stem O.D. IN	6.59 mm (0.259 in)	6.44 mm (0.254 in)	6.59 mm (0.259 in)	6.44 mm (0.254 in)
	EX	6.55 mm (0.258 in)	6.40 mm (0.252 in)	6.55 mm (0.258 in)	6.40 mm (0.252 in)
	Guide I.D. IN/EX	6.60 mm (0.260 in)	6.66 mm (0.262 in)	6.60 mm (0.260 in)	6.66 mm (0.262 in)
	Stem clearance IN	(0.0004 - 0.0006 in)	(0.004 ip)	(0.0004 - 0.0016  in)	(0.004 in)
	FX	0.050 = 0.080  mm	0.13 mm	0.050 = 0.080  mm	0.13 mm
		(0.0020 - 0.0031 in)	(0.005 in)	(0.0020 - 0.0031  in)	(0.005 in)
	Seat width	1.1 mm (0.04 in)	2.0 mm (0.08 in)	1.1 mm (0.04 in)	2.0 mm (0.08 in)
	Spring free length	39.0 mm (1.54 in)	37.5 mm (1.48 in)	39.0 mm (1.54 in)	37.5 mm (1.48 in)
Camshaft	Cam height IN	31.85 - 32.25 mm	31.10 mm	32.40 - 32.80 mm	32.25 mm
	(0,4 (n) 5 m	(1.254 - 1.270 in)	(1.224 in)	(1.276 - 1.291 in)	(1.270 in)
	EX	31.57 – 31.97 mm	30.80 mm	31.89 – 32.29 mm	31.75 mm
	Contractor Contractor	(1.243 – 1.259 in)	(1.213 in)	(1.256 – 1.271 in)	(1.250 in)
	Camshaft O.D.	15.984 mm (0.6293 in)	15.92 mm (0.627 in)	15.984 mm (0.6293 in)	15.92 mm (0.627 in)
Crankcase	Camshaft holder I.D.	16.0 mm (0.63 in)	16.05 mm (0.632 in)	16.0 mm (0.63 in)	16.05 mm (0.632 in)
Carburetor	Main iet	# 98		# 102	
	Float height	13.2 mm (0.52 in)		13.2 mm (0.52 in)	
	Pilot screw opening	2-5/8 turns out		2-1/4 turns out	
Spark plug	Gap	0.7 – 0.8 mm		0.7 – 0.8 mm	
		(0.028 - 0.031 in)		(0.028 - 0.031 in)	
Spark plug cap	Resistance	7.5 – 12.5 kΩ		7.5 – 12.5 kΩ	
Ignition coil	Resistance				
	Primary coil	0.8 – 1.0 Ω		0.8 – 1.0 Ω	
	Secondary coil	5.9 – 7.1 kΩ		5.9 – 7.1 kΩ	
	Air gap (at flywheel)	$0.4 \pm 0.2 \text{ mm}$		$0.4 \pm 0.2 \text{ mm}$	
		(0.016 ± 0.008 In)		(0.016 ± 0.008 In)	
Starter motor	Brush length			7.0 mm (0.28 in)	3.5 mm (0.14 in)
				(1) mm $(1)$ $(14$ m)	

# HONDA EP5000-EP650

# • GENERATOR

## **WTENANCE STANDARDS**

Part	runs or making technicaltem		St	andard	Service li	
Main winding	Resistance	EP5000	R type	0.8	3 – 1.0 Ω	
	Stendard	armi sorr	S type	0.6	σ – 0.9 Ω	
	3,150 ± 150 min* (rpm) 3,780 ± 150 min* (rpm) 6.0 = 8.5 kg/cm²	1.2 m	L type	0.1 - 0 0.7 - 0	3 Ω (120 V)/ .9 Ω (240 V)	stinis?
	(35 – 121 pai) or 600 mint (rpm)	EP6500S	R type	0.5	- 0.7 Ω	
	(m 888.E) mm 00.88	ung (3 236 kg)	S type	0.3	- 0.4 Ω	Slagve
0 10 min (0.000 m) 87.85 mm (3.455) m 0.12 mm	87 385 mm (3 4640 in) 10 015 - 0.052 mm		L type	0.1 – 0. 0.5 – 0	2 Ω (120 V)/ .7 Ω (240 V)	Skirt Ö. Piston-t
ield winding Resistance	EP5000	R type	18181.81 00000.55	- 65 Ω	Plagasia	
	20.00 mm (0.787 m)	iai (250) mic microsoft	S type	mm a te p 4 soo o 55	- 65 Ω	it-motel <sup>q</sup>
(0.0001 - 0.0006 in) (	100.500	L type	55	- 65 Ω	Conceller	
	(0.0012 - 0.0024 h)	EP6500S	R type	57	- 67 Ω	
	0.2 - 0.1 mm (0.01 - 6.02 in) (0.04 m)	Ani Agie	S type	57	- 67 Ω	
0.2 ~ 0.7 mm 2.0 mm (0.01 ~ 0.03 in) (0.04 in)	(n: 50.)	L type	(ni cou - be d) 57	- 67 Ω		
Exciter winding Resistance	EP5000	R type	1.0	- 1.2 Ω	a l'ung an	
25.026 mm (0.756 mm) 26.07 mm (0.429 m) 36.02 mm (1.4382 m) 56.07 mm (1.4329 m) 0.040 - 0.066 mm (0.12 mm (0.0216 - 0.065 mm (0.359 m)	36.025 mm (1.4183 m)	ans (1.420 in)	S type	0.8	- 1.0 Ω	bas pið
	(m e00.	L type	0.8	- 1.0 Ω		
	0.004 - 0.026 ini	EP6500S	R type	(ni 820.0 - 400.0) 1.1	- 1.3 Ω	
	35.985 mm (1 \$107 m)	(0) (1 4 15 (0)	S type	0.9	0 – 1.1 Ω	Leanard L
	(n) 160.0 ± 800.0)		L type	(m) ( 00.0 ± 800.0 0.9	- 1.1 Ω	
DC winding	Resistance	EP5000	R type	tor 100.0 ± 800 0 0.4	- 0.5 Ω	
	0.58 mm (0.260 in) 6.55 mm (0.258 in)	m (0.284 in) m (0.282 in)	S type	0.3	- 0.5 Ω	
	6.60 mm (0.260 in) 0.012 - 0.040 mm	m (0.282 in) 11 mm	L type	0.3	- 0.5 Ω	Stern ch
	(ni 8004 - 0.600 mm) nim 0.006 - 0.000 mm (ni 1.000 - 0.000 m)	EP6500S	R type	0.3	- 0.5 Ω	
(11 200.0			S type	0.3	- 0.4 Ω	
	38.0 mm (1.54 (n)	The forse way	L type	0.3	-0.4 Ω	grinds.
Carbon brush	Brush length	224 (n) - 4		9 mi	m (0.4 in)	5 mm (0.
Battery (EP6500S type only)	Specific gravity of	of electrolyte		1.27	0 – 1.290	Gamika
16.65 mm (0.832 m)	(ni 88 i), nen 8,8°	1 100 200 00.00	No.	Terzado imm s.a.	Greation in	enterinado e
			SI-			
				7.6 - 192 80		

# 5. TORQUE VALUES

# S. SPECIAL TOOLS

3

A CIMA MULTHING LANDING A	Thread tedmun loo not retered (mm) george - to		Torque			
tlevel inspection			N∙m	kg-m	ft-lb	
Connecting rod bolt	M8 x 1.25 (special bolt)	077	14	1.4	10	
Cylinder head bolt noissilsteni\ievor	M10 x 1.25 M 0000100 - 54	007	35	m 8.8 3.5 hb ebi	25	
Flywheel nut	M16 x 1.5 (Special nut)	910	115	11.5	83	
Rocker arm pivot lock nut	M6 x 0.5	077	10	1.0	ievin7 - F	
Rocker arm pivot bolt	M8 x 1.25 (Special bolt)	077	24	2.4 2.4	8 17 tach	
Crankcase cover bolt	M8 x 1.25	570	24	2.4	17	
Oil level switch joint nut	M10 x 1.25	0770	10	1.0	0 7 not, 35	
Fuel valve joint nut	M10 x 1.25	077	24	2.4	17	
Muffler mounting bolt	M8 x 1.25	079	24	2.4	17	
Air cleaner separator nut	M6 x 1.0 miles 0000103 - 86	079	7.5	0.75 ome	5.4	
Oil drain bolt	M12 x 1.5	0793	23	2.3	17	
Fuel tank bolt	M6 x 1.25	0751	10	1.0	T VR tes	
Air cleaner mounting nut on broom	M6 x 1.0 detel = 0000100 - 00	0778	8.5	0.85	6.1	
Starter solenoid terminal nut (EP6500S model)	M6 x 1.0	0778	3.8	0.38	2.2	
Standard torque values	5 mm bolt, nut	0778	5.5	0.55	4.0	
V/	6 mm bolt, nut		10	1.0	7	
oppositions opwar.	8 mm bolt, nut		24	2.4	17	
<ol> <li>(i)</li> <li>(i)</li> </ol>	10 mm bolt, nut	3	37.5	3.75	27	
	12 mm bolt, nut	51	55	5.5	40	

NOTE: Use standard torque values for items not specifically described in this table.

nacect and correct: P. 10-2, 4, 6

# HOND EP5000.EP65

# 6. SPECIAL TOOLS

M

No.	Tool name		Tool number	Application
1	Float level gauge	1.97	07401 - 0010000	Carburetor float level inspection
2	Sliding shaft		07736 - 0010100	Rotor removal
3	Sliding weight		07741 - 0010201	Rotor removal
4	Valve guide driver, 6.6 mm		00742 - 0010200	Valve guide removal/installation
5	Attachment, 32 x 35 mm		07746 - 0010100	Balancer bearing 6202 installation
6	Attachment, 72 x 75 mm		07746 - 0010600	Crankshaft bearing 6207 (crankcase side) insta
7	Driver		07746 - 0030100	Driver for tool 8
8	Attachment, 35 mm I.D.		07746 - 0030400	Crankshaft bearing 6207 (crankshaft side), tim
9	Pilot, 15 mm		07746 - 0040300	Balancer bearing 6202 installation
10	Pilot, 35 mm		07746 - 0040800	Crankshaft bearing 6207 (crankcase side) insta
11	Driver		07749 - 0010000	Driver for tools 9 and 10
12	Flywheel puller		07935 - 8050003	Flywheel removal
13	Weight		07936 - 3710200	Use with bearing remover, 15 mm (tool 18)
14	Bearing remover, 15 mm		07936 - KC10500	Balancer bearing 6202 removal
15	Valve guide reamer, 6.6 mm		07984 - ZE20000	Valve guide ID reaming
16	AVR tester		07KPJ - 0010000	AVR inspection
17	AVR tester adaptor		07FPJ - ZB40100	AVR inspection
18	Valve seat cutter, 45° 40.0 mm		07780 - 0010500	Intake valve seat reconditioning
19	Valve seat cutter, 45° 33.0 mm		07780 - 0010800	Exhaust valve seat reconditioning
20	Valve seat cutter, 32° 38.5 mm		07780 - 0012400	Intake valve seat reconditioning
21	Valve seat cutter, 32° 33.0 mm		07780 - 0012900	Exhaust valve seat reconditioning
22	Valve seat cutter holder, 6.6 mm		07781 - 0010201	Holder for tools 18, 19, 20 and 21



# 7. TROUBLESHOOTING

**DIVITARD STARTING** 



RPARE TEST

CVLINDER COLUPRESSION CHECK (Mechanical decoupores of anglauced)

- Remove the spark program of the restorn gauge in the spark plug hole
- Clark the engine several speed with the recoil starter and measure the compression

ompression \ 44-5-45.6-8.6 kg/cm² (85 - 121 ps 600 min \* rpm)

# HONDA EP5000-EP65



#### CYLINDER COMPRESSION CHECK

(Mechanical decompressor engaged)

- Remove the spark plug and install a compression gauge in the spark plug hole.
- Crank the engine several times with the recoil starter and measure the compression.

Compression         6.0 - 8.5 kg/cm² (85 - 121 psi) at           600 min <sup>-1</sup> (rpm)	
--	--



#### **c. IGNITION SYSTEM**





#### SPARK TEST

coator Lore using a multimeter or ohmmeter i

- 1) Remove the spark plug.
- Install the spark plug to the spark plug cap and ground the side electrode against the cylinder head cover.
- Turn the engine switch to the "ON" position, pull the recoil starter and check to see if sparks jump across the electrodes.

#### AWARNING

- Never hold the spark plug lead with wet hands while performing this test.
- Make sure that no fuel has been spilled on the engine and the plug is not wet with fuel.
- To avoid fire hazards, do not allow sparks near the plug hole.





#### GENERATOR

![](_page_23_Figure_2.jpeg)

![](_page_24_Figure_0.jpeg)

![](_page_25_Figure_0.jpeg)

# HOND

![](_page_26_Figure_1.jpeg)

# MAINTENANCE

# 8. MAINTENANCE SCHEDULE

REGULAR SERV Operating hour er comes first.	ICE PERIOD interval, whichev-	Each use	First month or	Every 3 months	Every 6 months	Every year or
ITEM		BATTERY	201115	01 50 1115	or rooms	300 1115
Engine oil	Check level	0		016	14	Mr.A
	Change		0		0	Salais-
Air cleaner	Check	0	743	and the	and	autona
	Clean	ales of tests a	AIR CLE	0 (1)		- Company
Sediment cup	Clean	( ) )	vibeteage	skin cancer if	euro von lin e	lipna hael
Spark plug	Check-adjust	Contraction day th	d periods14	in for prolonge	act wild the si	tnoo ni stel
Valve clearance	Check-adjust	Manri entrenne	No basu e	niess you hand	lits of ti sized	0
Fuel tank & filter	Clean	1	Soon as	Sold bris qs	hands with so	tuay nO.w
Fuel line	Check Replace if necessary	cleaner cass a prevent dirt fin arburetor	OF REACH	Every 2 years	<b>ងអង្កេ</b> ndling use MilO	possible am

(1) Service more frequently when used in dusty areas.

nant. We suggest that you take it o your local waste disposal site, researching trash or pour it onto the ground, we with save bigg of

Draining can be performed rapidly and completely when the engine is still warm.

Drain the engine oil with the engine warm and in a horizontal position to assure complete and rapid draming.

) Remove the oil filler cap and oil drain bolt. Allow the oil to drain completely,

Reinstall the drain bolt, and tighten it securely.

TOROUE: 23 N-m (2.3 kg-m, 17 ft-fb

 Fill the transcase with the recommended engine oil to the lower edge of the oil filler neck.

Engine oil capacity 1.1.2 (1.16 US qt, 0.97 Imp qt)

A Reinstall the or biller of

30 tion SG. SF.

![](_page_27_Figure_17.jpeg)

# **3. MAINTENANCE**

# HOND EP5000.EP65

- **1. ENGINE OIL**
- 2. AIR CLEANER
- **3. SPARK PLUG**
- 4. GOVERNOR

- **5. VALVE CLEARANCE**
- 6. CARBURETOR
  - 7. SEDIMENT CUP/FUEL TANK FILTER
- 8. BATTERY

# **1. ENGINE OIL**

#### AWARNING

Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil. KEEP OUT OF REACH OF CHILDREN.

![](_page_28_Figure_13.jpeg)

#### NOTE

- · Dispose of used motor oil in a manner that is compatible with the environment. We suggest that you take it in sealed container to your local waste disposal site, or service station for reclamation.
- · Do not throw it in the trash or pour it onto the ground, down sewers or drains.
- · Draining can be performed rapidly and completely when the engine is still warm.
- · Drain the engine oil with the engine warm and in a horizontal position to assure complete and rapid draining.
- 1) Remove the oil filler cap and oil drain bolt. Allow the oil to drain completely.
- 2) Reinstall the drain bolt, and tighten it securely.

#### TORQUE: 23 N·m (2.3 kg-m, 17 ft-lb)

3) Fill the crankcase with the recommended engine oil to the lower edge of the oil filler neck.

Engine oil capacity	1.1 ℓ (1.16 US qt, 0.97 Imp qt)
Trans entrany te	
Recommended	SAE 10 W - 30

4) Reinstall the oil filler cap.

![](_page_28_Figure_25.jpeg)

![](_page_28_Figure_26.jpeg)

# 2. AIR CLEANER

#### AWARNING

- Never use gasoline or low flash point solvents for cleaning the air cleaner element. A fire or explosion could result.
- Unsnap the air cleaner cover springs and remove the air cleaner cover.
- Remove the air cleaner element. Carefully check the element for holes or tears and replace if damaged. Clean the element.
- 3) Clean in warm soapy water, rinse and allow to dry thoroughly. Or clean in nonflammable solvent and allow to dry. Dip the element in clean engine oil and squeeze out all excess oil.
- 4) Wipe dirt from the inside of the air cleaner case and cover, using a moist rag. Be careful to prevent dirt from entering the air duct that leads to the carburetor.
- 5) Reinstall the element and cover. Tighten the air cleaner bolt securely.

#### CAUTION

 Carefully check the element for holes or tears and replace as required. Damaged element will allow dirt to pass into the engine, causing rapid wear. Always clean the filter housing and air passages before installing clean element.

![](_page_29_Figure_11.jpeg)

![](_page_29_Picture_12.jpeg)

#### NOTE

 The engine will run poorly when the air cleaner needs maintenance. If it runs better without the air cleaner than it does with the elements, or if the length of time between needed cleanings keeps getting shorter, replace the elements. Under extremely dusty conditions such as volcanic ash, silt, etc., the system may need daily maintenance.

# A. GOVERNOR

- Lossen the full on the governor it in hisch bolt, and more the governor arm to fully opening throttle. Notate the Governor arm to fully opening the solar as it will go in the same direction the governor arm receded to open the throttle.
- Start the engine and allow inforwerm up to normal operethop temporature. Move the throttle lawer, to run the engine at the standard maximum speed, and adjust the throttle lever limiting screw so the throttle lever cannot be moved per that their eview essent of

# 3. SPARK PLUG

- 1) Clean any dirt from around the spark plug.
- 2) Remove the plug cap, and use a spark plug wrench to remove the plug.

![](_page_29_Figure_21.jpeg)

- Visually inspect the spark plug. Discard it if the insulator is cracked or chipped. The center electrode should have square edges and the side electrode should not eroded.
- 4) Remove any deposits with a wire brush.
- 5) Check the plug gap with a wire-type feeler gauge and correct the gap as necessary by bending the side electrode.

Spark plug gap	0.7 – 0.8 mm (0.028 – 0.031 in)
Recommended	BPR6ES (NGK)
spark plug	W20EPR-U (NIPPONDENSO)

6) Make sure the sealing washer is in good condition.

7) Install the plug fingertight to seat the washer, then tighten with a plug wrench (an additional 1/2 turn if a new plug) to compress the sealing washer. If you are reusing a plug, tighten 1/8 – 1/4 turn after the plug seats.

#### CAUTION

 The spark plug must be securely tightened. An improperly tightened plug can become very hot and possibly damage the engine.

Never use spark plug with an improper heat range.

# 4. GOVERNOR

- 1) Loosen the nut on the governor arm pinch bolt, and move the governor arm to fully open the throttle.
- 2) Rotate the governor arm shaft as far as it will go in the same direction the governor arm moved to open the throttle.
- 3) Start the engine and allow it to warm up to normal operating temperature. Move the throttle lever to run the engine at the standard maximum speed, and adjust the throttle lever limiting screw so the throttle lever cannot be moved past that point.

Standard maximum speed	50 Hz: 3,150 ± 150 rpm 60 Hz: 3,750 ± 150 rpm	
engine oil	Service clouds relian set (Sh.	
		ch to

![](_page_30_Figure_14.jpeg)

HONDA

ug wrench to

hereiclar

LIMITING SCREW

# **5. VALVE CLEARANCE**

Valve clearance inspection and adjustment must be performed with the engine cold.

- 1) Remove the spark plug cap.
- Remove the cylinder head cover bolt, cylinder head cover and gasket.

#### NOTE

- After the cylinder head cover is removed, engine oil may flow.
   Be sure to wipe up any flowed oil.
- Games and sheking met
- Remove the recoil starter.
   Set the piston at top dead center of the compression stroke (both valves fully closed). The triangular mark on the starter pulley will align with the top hole on the fan cover when the piston is at top dead center of the compression or exhaust stroke.
- Insert a feeler gauge between the rocker arm and valve to measure valve clearance.

Standard valve	IN	0.15 ± 0.02 mm (0.006 ± 0.001 in)
clearance	EX	0.20 ± 0.02 mm (0.008 ± 0.001 in)

overfilled, electrolyte may overflow and correct genorator components, learnediotely week of any spilled

6) If adjustment is necessary, proceed as follows:

- a. Hold the rocker arm pivot and loosen the rocker arm pivot lock nut.
- b. Turn the rocker arm pivot to obtain the specified clearance.
- c. Retighten the rocker arm pivot lock nut while holding the rocker arm pivot.
- d. Recheck valve clearance after tightening the rocker arm pivot lock nut.

nest the charger positive (+) terminal to the battery tive (+) terminal and the charger negative (-) termito the battery negative (-) terminal.

![](_page_31_Figure_18.jpeg)

# **6. CARBURETOR**

- 1) Start the engine and allow it to warm up to normal operating temperature.
- 2) With the engine idling, turn the pilot screw in or out to the setting that produces the highest idle rpm. The correct setting will usually be obtained at approximately the following number of turns out from the fully closed (lightly seated) position.

Pilot corow opening	EP5000	2 - 5/8 turns out
Pilot screw opening	EP6500S	2 – 1/4 turns out

![](_page_31_Picture_23.jpeg)

# (SEDIMENT CUP)

![](_page_31_Picture_25.jpeg)

Gasoline is extremely flammable and is explosive under remain constrons. Do not smoke or allow

- flames or eports in the acca. After installing the final atrained gup, check for leaks and make sure the weake with before starting the
  - and make sure the weaky dry hefore starting engine. R399U

# HONDA EP5000-EP650

![](_page_32_Picture_1.jpeg)

# 7. SEDIMENT CUP/FUEL TANK FILTER

#### AWARNING

- Gasoline is extremely flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks in the area.
- After installing the fuel strainer cup, check for leaks, and make sure the area is dry before starting the engine.

#### **(SEDIMENT CUP)**

- 1) Turn the fuel valve to the OFF position. Remove the sediment cup, O-ring, and fuel valve filter.
- Wash the sediment cup and filter in nonflammable or high flashpoint solvent. Inspect the filter to be sure it is undamaged.
- Install the filter, O-ring, and sediment cup. Tighten the sediment cup to the specfied torque value.

#### TORQUE: 4 N·m (0.4 kg-m, 2.9 ft-lb)

#### **(FUEL TANK FILTER)**

- 1) Drain the fuel from the fuel tank into a suitable container.
- Unscrew the fuel valve nut to disconnect the fuel valve, and remove the fuel tank filter.
- 3) Wash the filter in nonflammable or high flashpoint solvent. Inspect the filter to be sure it is undamaged.

#### NOTE

• If necessary, also flush and clean the fuel tank.

 Check to be sure the O-ring is in place, and install the filter and fuel valve. Tighten the fuel valve nut to the specified torque value.

#### TORQUE: 24 N·m (2.4 kg-m, 17 ft-lb)

![](_page_32_Figure_19.jpeg)

![](_page_32_Figure_20.jpeg)

# BURETON

the engine and allow it to warm up to normal operptemperature referengine ruling, turn the pilot acrow in or out to setting that produces the highest idle rpm. The consetting will us all the obtained at approximately the wing humber of turne out from the fully closed by seated) position

# YWHEEL/STARTER MOTOR

# HONDA EP5000·EP65

![](_page_33_Figure_2.jpeg)

#### SPARK PLUG CAP

Measure the resistance of the spark plug cap by touching one test lead at the wire end of the cap and the other at the spark plug end.

Resistance	7.5 – 12.5 kΩ
------------	---------------

Replace the spark plug cap if the resistance is not within the range specified.

# SPARK PLUG CAP

#### CHARGE COIL (EP6500S model only)

Measure the resistance between the wire terminal and ground.

Resistance	3.0 – 4.0 Ω

![](_page_34_Figure_9.jpeg)

#### STARTER SOLENOID

Connect a 12 V battery between the starter terminal and the solenoid body and check for continuity between the terminals. Continuity should exist when the battery is connected and not exist when battery is disconnected.

![](_page_34_Figure_12.jpeg)

#### BRUSH LENGTH

Measure the brush length. If brush length is less than service limit, replace the brush and brush holder plate.

Standard	Service limit
7.0 mm (0.28 in)	3.5 mm (0.14 in)

![](_page_34_Figure_16.jpeg)

# HONDA EP5000·EP650

![](_page_35_Figure_1.jpeg)

#### CARBON BRUSH/SLIP RING

- Remove the brush holder. Check the brush for length, wearing condition or any other defect. Replace if the length is less than 5 mm (0.2 in).
- 2) Visually inspect the slip rings for freedom from dust, rust or other damage. If necessary, wipe them with a clean lint-free cloth. If they are rusted or damaged, remove the rotor and dress with fine emery cloth (No. 500 – 600).

![](_page_36_Figure_4.jpeg)

#### FIELD WINDING

a criss pattern in 2

Remove the brushes and measure resistance between the slip rings.

If the specified resistance is obtained at the slip rings, but

	81	COLUMN STATE COLUMN	
Specified	EP5000	55 – 65 Ω	
resistance	EP6500S	57 – 67 Ω	1

not at the brush terminals, clean or replace the brushes. If the specified resistance is not obtained at the slip rings, clean or replace the rotor.

#### MAIN WINDING (AC)

Using an ohmmeter, measure the resistance between the AC output terminals.

Specified resistance	drop mto 1	R type	0.8 – 1.0 Ω
	EP5000	S type	0.6 – 0.9 Ω
		L type	0.1 – 0.3 Ω (120 V)/ 0.7 – 0.9 Ω (240 V)
	ROCKER	R type	0.5 – 0.7 Ω
		S type	0.3 – 0.4 Ω
	EP05005	L type	0.1 – 0.2 Ω (120 V)/ 0.5 – 0.7 Ω (240 V)

#### NOTE

• Set the voltage selector switch to 120 V position (L type only).

If the resistance is zero or infinity, replace the stator.

#### • EXCITER WINDING

Using an ohmmeter, measure the resistance between the Blue and Blue in the 4P connector.

	505000	R type	1.1 – 1.2 Ω
Specified	EP5000	S, L types	0.8 – 1.0 Ω
resistance	E DOE OOO	R type	1.1 – 1.3 Ω
	EP65005	S, L types	0.9 – 1.1 Ω

If the resistance is zero or infinity, replace the stator.

![](_page_36_Figure_21.jpeg)

![](_page_36_Figure_22.jpeg)

![](_page_36_Figure_23.jpeg)

#### CARBON BRUSH/SLIP RING

- Remove the brush holder. Check the brush for length, wearing condition or any other defect. Replace if the length is less than 5 mm (0.2 in).
- 2) Visually inspect the slip rings for freedom from dust, rust or other damage. If necessary, wipe them with a clean lint-free cloth. If they are rusted or damaged, remove the rotor and dress with fine emery cloth (No. 500 – 600).

![](_page_37_Picture_4.jpeg)

#### FIELD WINDING

A CONTRACTOR OF A CONTRACTOR OFTA CONTRACTOR O

Remove the brushes and measure resistance between the slip rings.

If the specified resistance is obtained at the slip rings, but

Specified	EP5000	55 – 65 Ω	
resistance	EP6500S	57 – 67 Ω	

not at the brush terminals, clean or replace the brushes. If the specified resistance is not obtained at the slip rings, clean or replace the rotor.

#### MAIN WINDING (AC)

#### (Exhaust verve o

Using an ohmmeter, measure the resistance between the AC output terminals.

volve may	drop lette t	R type	0.8 – 1.0 Ω
Specified resistance	EP5000	S type	0.6 – 0.9 Ω
		L type	0.1 – 0.3 Ω (120 V)/ 0.7 – 0.9 Ω (240 V)
	EDCE00C	R type	0.5 – 0.7 Ω
		S type	0.3 – 0.4 Ω
DOKER MELE VIOT	EF00005	L type	0.1 – 0.2 Ω (120 V)/ 0.5 – 0.7 Ω (240 V)

NOTE

• Set the voltage selector switch to 120 V position (L type only).

If the resistance is zero or infinity, replace the stator.

#### EXCITER WINDING

Using an ohmmeter, measure the resistance between the Blue and Blue in the 4P connector.

	EBEOOO	R type	1.1 – 1.2 Ω
Specified resistance	EF5000	S, L types	, L types 0.8 – 1.0 Ω
	EBCEOOC	R type	1.1 – 1.3 Ω
	EP05005	S, L types	0.9 – 1.1 Ω

If the resistance is zero or infinity, replace the stator.

![](_page_37_Picture_22.jpeg)

![](_page_37_Picture_23.jpeg)

![](_page_37_Figure_24.jpeg)

# HONDA

![](_page_38_Figure_1.jpeg)

![](_page_39_Picture_0.jpeg)

**CYLINDER HEAD** 

COVER

## DISASSEMBLY:

Push down and slide the retainer to the side, so the valve stem slips through the hole at the side of the retainer.

#### REASSEMBLY:

The exhaust valve retainer has a larger center recess than the intake valve retainer, so it can accept the valve rotator.

#### CAUTION

· Do not remove the valve spring retainers while the cylinder head is installed, or the valves will drop into the cylinder.

#### CYLINDER HEAD COVER GASKET

![](_page_39_Picture_8.jpeg)

#### b. INSPECTION

#### VALVE SPRING FREE LENGTH

Measure the free length of the valve springs.

Standard	Service limit
39.0 mm (1.54 in)	37.5 mm (1.48 in)

Replace the springs if they are shorter than the service limit.

VALVE SEAT WIDTH

Measure the valve seat width.

Standard	Service limit
1.1 mm (0.04 in)	2.0 mm (0.08 in)

If the valve seat width is under the standard, or over the service limit, recondition the valve seat. (P. 10-5)

![](_page_39_Picture_22.jpeg)

![](_page_39_Picture_23.jpeg)

GASKET

#### CYLINDER HEAD

Remove carbon deposits from the combustion chamber. Clear off any gasket material from the cylinder head surface. Check the spark plug hole and valve areas for cracks. Check the cylinder head for warpage with a straight edge and a feeler gauge.

2)	Service limit	0.10 mm (0.004 in)
3	Continue to rote and re- Continue to rote a re- It from the role is a re-	- Hiclockwise while removing
		detro detro as nec-
		owinality and to remuve any out-
		An official be straight, round an ident insent the volve and an official operate smoothly, wisy an plant change installation.
		San Sanaged. San Sanar (P. 10-4).

![](_page_40_Figure_4.jpeg)

the cleanance within tolerance. If so, replace any guide as nec reserv, and ream to fit, if the story to-quide clearance exceed

![](_page_40_Figure_6.jpeg)

#### VALVE STEM O.D.

Inspect each valve for face irregularities, bending or abnormal stem wear. Replace the valve if necessary. Measure and record each valve stem O.D.

Standard		Service limit
IN	6.59 mm (0.259 in)	6.44 mm (0.254 in)
EX	6.55 mm (0.258 in)	6.40 mm (0.252 in)

Replace the valves if their O.D. is smaller than the service limit.

#### • VALVE GUIDE I.D.

NOTE

Clean the valve guides to remove any carbon deposits before measuring.

Measure and record each valve guide I.D.

Standard	Service limit
6.60 mm (0.260 in)	6.66 mm (0.262 in)

Replace the guides if they are over the service limit. (P. 10-4).

![](_page_40_Figure_17.jpeg)

![](_page_40_Figure_18.jpeg)

#### GUIDE-TO-STEM CLEARANCE

Subtract each valve stem O.D. from the corresponding guide I.D. to obtain the stem-to-guide clearance.

	Standard	Service limit
IN	0.010 – 0.040 mm (0.0004 – 0.0016 in)	0.11 mm (0.004 in)
EX	0.050 – 0.080 mm (0.0020 – 0.0031 in)	0.13 mm (0.005 in)

If the stem-to-guide clearance exceeds the service limit, determine if the new guide with standard dimensions would bring the clearance within tolerance. If so, replace any guide as necessary and ream to fit. If the stem-to-guide clearance exceeds the service limit with new guides, replace the valves as well.

#### NOTE

 Recondition the valve seats whenever the valve guides are replaced (P. 10-5)

#### • THERMO SWITCH

- Suspend the thermo switch in a container of coolant or oil. Be sure the switch does not touch the container.
- Heat the liquid and note its temperature when the thermo switch closes and there is continuity between the thermo switch wire connectors.

#### NOTE

Don't allow the thermometer to touch the container.

CONTINUITY	98° – 102°C (208 – 216°F)
NO CONTINUITY	Less than 91°C (196°F)

#### c. VALVE GUIDE REPLACEMENT

 Support the cylinder head with wooden blocks. Drive the valve guides out of the head from the combustion chamber side.

#### CAUTION

10-4

- When driving the valve guides out, be careful not to damage the head.
- Install the new valve guides from the valve spring side of the cylinder head.

Exhaust side: Drive the exhaust valve guide until the clip is fully seated as shown.

Intake side: Drive the intake valve guide to the specified height (measured from the top of the valve guide to the cylinder casting as shown).

![](_page_41_Figure_20.jpeg)

3) After installation, inspect the valve guide for damage; replace the guide if damaged.

![](_page_41_Figure_22.jpeg)

![](_page_41_Figure_23.jpeg)

![](_page_41_Figure_24.jpeg)

![](_page_41_Figure_25.jpeg)

#### VALVE GUIDE REAMING

NOTE

- For best results, be sure the cylinder head is at room temperature before reaming valve guides.
- 1) Coat the reamer and valve guide with cutting oil.
- 2) Rotate the reamer clockwise through the valve guide the full length of the reamer.
   3) Continue to rotate the reamer clockwise while removing it from the valve guide.
- Thoroughly clean the cylinder head to remove any cutting residue.
- 5) Check the valve guide bore; it should be straight, round and centered in the valve guide. Insert the valve and check operation. If the valve does not operate smoothly, the guide may have been bent during installation. Replace the valve guide if it is bent or damaged.
- 6) Check the Valve Guide-to-Stem Clearance (P. 10-4).

![](_page_42_Figure_8.jpeg)

S. TOOL

REAMER 07984 - ZE20000

VALVE GUIDE

#### d. VALVE SEAT RECONDITIONING

 Thoroughly clean the combustion chamber and valve seats to remove carbon deposits.

Apply a light coat of Prussian Blue or erasable felt-tipped marker ink to the valve face.

2) Insert the valve, and snap it closed against its seat several times. Be sure the valve does not rotate on the seat. The transferred marking compound will show any area of the seat that is not concentric.

#### NOTE

- Follow the instructions of the valve seat cutter manufacturer.
- Using a 45° cutter, remove enough material to produce a smooth and concentric seat.
   Turn the cutter clockwise, never counterclockwise.
   Continue to turn the cutter as you lift it from the valve seat.
- 4) Use the  $30^{\circ} 32^{\circ}$  and  $60^{\circ}$  cutters to narrow and adjust the valve seat so that it contacts the middle of the valve face. The  $30^{\circ} - 32^{\circ}$  cutter removes material from the top edge (contact too high). The  $60^{\circ}$  cutter removes material from the bottom edge (contact too low). Be sure that the width of the finished valve seat is within specification.

![](_page_42_Figure_17.jpeg)

![](_page_42_Figure_18.jpeg)

![](_page_42_Figure_19.jpeg)

#### VALVE SEAT WIDTH

Standard	Service limit
1.1 mm (0.04 in)	2.0 mm (0.08 in)

- 5) Make a light pass with 45° cutter to remove any possible burrs at the edges of the seat.
- 6) After resurfacing the seats, inspect for even valve seating. Apply Prussian Blue compound or erasable felttipped marker ink to the valve faces. Insert the valve, snap it closed against its seat several times. Be sure the valve does not rotate on the seat.

The seating surface, as shown by the transferred marking compound, should have good contact all the way around.

7) Lap the valves into their seats, using a hand valve lapper and lapping compound (commercially available).

#### CAUTION

 To avoid severe engine damage, be sure to remove all lapping compound from the engine before reassembly.

#### NOTE

Adjust valve clearance after reassembly.

# VALVE GOIDE RIGHT REENERY

Support the collecter head wangeboden blocks. Drive the server guides out of the head from the compact on and ber side.

#### AUTION

 When driving the valve guides out, be careful nor to compare the head

#### HOIH OOT TOATMOS

the cylinder head

- is fully seared as shown.
- heid/0400007047003/e kop of the velv guide to the calindateasting as shown).
- water grace install flan height ( 3.0 mm (0.12 in)
- Alter modellation, mapping the valve guide for damage

![](_page_43_Figure_22.jpeg)

![](_page_43_Picture_23.jpeg)

Commus (2 Juni the cutter as you him in them the valve seet. ) Use the 30° - 22° and 50° cutters to nerrow and adjus the valve sept so that it contacts the middle of the valve tace. The 30 - 32° cuter removes material from the top adoe (contact too high). The 60° cutter removes material

from the bottom edge (contact too low) be sure that the width of the inished valve seat is within specification.

# HONDA EP5000-EP6500S 11. CRANKCASE COVER/GOVERNOR

1. CRANKCASE COVER/GOVERNOR

CRANKEHAFT BEARING (6207)

![](_page_44_Figure_3.jpeg)

12. CRANKSHAFT/PIS

# HONDA EP5000·EP6500S

![](_page_45_Figure_2.jpeg)

![](_page_46_Picture_1.jpeg)

#### • TIMING GEAR/BALANCER GEAR

#### DISASSEMBLY:

Make a mark on the crankshaft, balancer gear and timing gear, then press the timing or balancer gear out of the crankshaft using a commercially available bearing puller and hydraulic press.

![](_page_46_Picture_5.jpeg)

#### REASSEMBLY:

- 1) BALANCER DRIVE GEAR OR GOVERNOR DRIVER GEAR Using the old gear for reference, make a mark at the same position on the new gear. Using a hydraulic press, driver and suitable attachment,
  - press the new gear onto the crankshaft.

![](_page_46_Picture_9.jpeg)

# 2) TIMING GEAR Using the old gear for reference, make a mark at the same position on the new gear. Using a hydraulic press and following tools, press onto the crankshaft. TOOLS: Driver, 40 mm I.D. 07746 - 0030100 Attachment, 35 mm I.D. 07746 - 0030400 Attachment, 35 mm I.D. 07746 - 0030400

![](_page_47_Picture_1.jpeg)

#### b. INSPECTION

#### • OIL LEVEL SWITCH

Check continuity between the yellow and green switch leads with an ohmmeter.

- 1) Hold the switch in its normal position. The ohmmeter should read zero resistance.
- Hold the switch upside down. The ohmmeter should read infinite (∞) resistance.
- 3) Inspect the float by dipping the switch into a container of oil. The ohmmeter reading should go from zero to infinity as the switch is lowered.

![](_page_47_Figure_8.jpeg)

CAMSHAFT

**PUNCH MARKS** 

#### CRANKSHAFT BEARING FREE PLAY

- 1) Clean the bearing in solvent and dry it.
- Spin the bearing by hand and check for play. Replace the bearing if it is noisy or has excessive play.

![](_page_47_Figure_12.jpeg)

## CYLINDER I.D.

Measure and record the cylinder I.D. at three levels in both "X" axis (perpendicular to crankshaft) and "Y" axis (parallel to crankshaft). Take the maximum reading to determine cylinder wear and taper.

	Standard	Service limit
EP5000	82.00 mm (3.228 in)	82.17 mm (3.235 in)
EP6500S	88.00 mm (3.465 in)	88.17 mm (3.471 in)

![](_page_48_Figure_4.jpeg)

#### • PISTON SKIRT O.D.

Measure and record the piston O.D. at a point 10 mm (0.4 in) from the bottom of the skirt and 90° to the piston pin bore.

	Standard	Service limit
EP5000	81.985 mm (3.2277 in)	81.85 mm (3.222 in)
EP6500S	87.985 mm (3.4640 in)	87.85 mm (3.459 in)

![](_page_48_Figure_8.jpeg)

#### PISTON-TO-CYLINDER CLEARANCE

Standard	Service limit	
0.015 – 0.052 mm	0.12 mm	
(0.0006 - 0.0020 in)	(0.005 in)	

#### • PISTON RING SIDE CLEARANCE

	Standard	Service limit	-
Top/Second	0.030 – 0.060 mm (0.0012 – 0.0024 in)	0.15 mm (0.006 in)	

![](_page_48_Figure_13.jpeg)

	Standard	Service limit
Top/Second	0.2 – 0.7 mm	1.0 mm
Oil	(0.01 – 0.03 in)	(0.04 in)

#### NOTE

• Use the top of the piston to position the ring horizontally in the cylinder.

![](_page_48_Figure_17.jpeg)

![](_page_48_Figure_18.jpeg)

![](_page_49_Figure_1.jpeg)

![](_page_49_Figure_2.jpeg)

<ul> <li>PISTON PIN BORE</li> </ul>	I.D.
-------------------------------------	------

Standard Ch	Service limit
20.002 mm	20.042 mm
(0.7875 in)	(0.7891 in)

#### • PISTON-TO-PISTON PIN BORE CLEARANCE

Standard	Service limit
0.002 – 0.014 mm	0.08 mm
(0.0001 – 0.0006 in)	(0.003 in)

![](_page_49_Figure_7.jpeg)

![](_page_49_Figure_8.jpeg)

•	CONM	NECT	ING	ROD	BIG	END	I.D.
---	------	------	-----	-----	-----	-----	------

CONNECTING ROD BIG	END I.D.	d measure the plastigause.	lemove the connecting rod and
Standard	Service limit	Service limit	((())) - busbasta
36.025 mm (1.4183 in)	36.07 mm (1.420 in)	0.12 mm (0.005 in)	0.040 - 0.060 m - 0.000 m - 0.0000 m - 0.000 m - 0.0000 m - 0.000 m - 0.0000 m - 0.0000 m - 0.0000 m - 0.0
DISASSEMBLY	EMBLY	and englace the	

#### CRANK PIN O.D.

Standard	Service limit
35.985 mm	35.93 mm
(1.4167 in)	(1.415 in)
	And the second se

![](_page_50_Figure_7.jpeg)

#### CONNECTING ROD BIG END SIDE CLEARANCE

Standard	Service limit
0.1 – 0.7 mm	1.0 mm
(0.004 – 0.028 in)	(0.04 in)

![](_page_50_Picture_11.jpeg)

#### CONNECTING ROD BIG END OIL CLEARANCE

- 1) Clean all from the crankpin and connecting rod big end surfaces.
- 2) Place a piece of plastigauge on the crankpin, install the connecting rod and cap, and tighten the bolts to the specified torque.

#### TORQUE: 14 N·m (1.4 kg-m, 10 ft-lb)

#### NOTE

Do not rotate the crankshaft while the plastigauge is in . place.

![](_page_50_Figure_18.jpeg)

3) Remove the connecting rod and measure the plastigauge.

Standard	Service limit
0.040 – 0.066 mm	0.12 mm
(0.0016 – 0.0026 in)	(0.005 in)

4) If the clearance exceeds the service limit, replace the connecting rod and recheck the clearance.

![](_page_51_Picture_4.jpeg)

#### • CAMSHAFT CAM HEIGHT

brebace		Standard	Service limit	
EP5000 EX	IN	31.85 – 32.25 mm (1.254 – 1.270 in)	31.10 mm (1.224 in)	
	31.57 – 31.97 mm (1.243 – 1.259 in)	30.80 mm (1.213 in)		
EP6500S	IN	32.40 – 32.80 mm (1.276 – 1.291 in)	32.25 mm (1.270 in)	
	EX	31.89 – 32.29 mm (1.256 – 1.271 in)	31.75 mm (1.250 in)	

![](_page_51_Picture_7.jpeg)

#### • CAMSHAFT O.D.

Standard	Service limit	
15.984 mm (0.6293 in)	15.92 mm (0.627 in)	
	Service Imut	

![](_page_51_Picture_10.jpeg)

# CAMSHAFT HOLDER I.D.

![](_page_51_Figure_12.jpeg)

![](_page_51_Figure_13.jpeg)