

## How to use this manual

---

# A Few Words About Safety

## SERVICE INFORMATION

The service and repair information contained in this manual is intended for use by qualified, professional technicians. Attempting service or repairs without the proper training, tools, and equipment could cause injury to you and/or others. It could also damage this Honda product or create an unsafe condition.

This manual describes the proper methods and procedures for performing service, maintenance, and repairs. Some procedures require the use of special tools. Any person who intends to use a replacement part, service procedure, or a tool that is not recommended by Honda must determine the risks to their personal safety and the safe operation of this product.

If you need to replace a part, use Honda Genuine parts with the correct part number or an equivalent part. We strongly recommend that you do not use replacement parts of inferior quality.

## For Your Customer's Safety

Proper service and maintenance are essential to the customer's safety and the reliability of this product. Any error or oversight while servicing this product can result in faulty operation, damage to the product, or injury to others.

### **⚠ WARNING**

Improper service or repairs can create an unsafe condition that can cause your customer or others to be seriously hurt or killed.

Follow the procedures and precautions in this manual and other service materials carefully.

## For Your Safety

Because this manual is intended for the professional service technician, we do not provide warnings about many basic shop safety practices (e.g., Hot parts-wear gloves). If you have not received shop safety training or do not feel confident about your knowledge of safe servicing practices, we recommend that you do not attempt to perform the procedures described in this manual.

Some of the most important general service safety precautions are given below. However, we cannot warn you of every conceivable hazard that can arise in performing service and repair procedures. Only you can decide whether or not you should perform a given task.

### **⚠ WARNING**

Failure to properly follow instructions and precautions can cause you to be seriously hurt or killed.

Follow the procedures and precautions in this manual carefully.

## Important Safety Precautions

Make sure you have a clear understanding of all basic shop safety practices and that you are wearing appropriate clothing and using safety equipment. When performing any service task, be especially careful of the following:

- Read all of the instructions before you begin, and make sure you have the tools, the replacement or repair parts, and the skills required to perform the tasks safely and completely.
- Protect your eyes by using proper safety glasses, goggles, or face shields anytime you hammer, drill, grind, or work around pressurized air, pressurized liquids, springs, or other stored-energy components. If there is any doubt, put on eye protection.
- Use other protective wear when necessary, for example gloves or safety shoes. Handling hot or sharp parts can cause severe burns or cuts. Before you grab something that looks like it can hurt you, stop and put on gloves.
- Protect yourself and others whenever you have equipment hoisted in the air. Anytime you lift this product with a hoist, make sure that the hoist hook is securely attached to the product.

Make sure the engine is off before you begin any servicing procedures, unless the instruction tells you to do otherwise. This will help eliminate several potential hazards:

- Carbon monoxide poisoning from engine exhaust. Be sure there is adequate ventilation whenever you run the engine.
- Burns from hot parts. Let the engine and exhaust system cool before working in those areas.
- Injury from moving parts. If the instruction tells you to run the engine, be sure your hands, fingers and clothing are out of the way.

Gasoline vapors and hydrogen gasses from batteries are explosive. To reduce the possibility of a fire or explosion, be careful when working around gasoline or batteries.

- Use only a nonflammable solvent, not gasoline, to clean parts.
  - Never store gasoline in an open container.
  - Keep all cigarettes, sparks, and flames away from the battery and all fuel-related parts.
-

## INTRODUCTION

This supplement covers the construction, function, and servicing procedures of the Honda ER2500CX SK type generator.

For service information that is not covered in this supplement, please refer to the ER2500CX base shop manual (part number 82Z4100).

All information contained in this manual is based on the latest product information available at the time of printing. We reserve the right to make changes at anytime without notice.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form, by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission of the publisher. This includes text, figures, and tables.

As you read this manual, you will find information that is preceded by a **NOTICE** symbol. The purpose of this message is to help prevent damage to this Honda product, other property, or the environment.

## SAFETY MESSAGES

Your safety and the safety of others are very important. To help you make informed decisions, we have provided safety messages and other safety information throughout this manual. Of course, it is not practical or possible to warn you about all the hazards associated with servicing these products. You must use your own good judgement.

You will find important safety information in a variety of forms, including:

- Safety Labels – on the product.
- Safety Messages – preceded by a safety alert symbol  
⚠ and one of three signal words, DANGER, WARNING, or CAUTION.  
These signal words mean:

**⚠ DANGER** You WILL be KILLED or SERIOUSLY HURT if you don't follow instructions.

**⚠ WARNING** You CAN be KILLED or SERIOUSLY HURT if you don't follow instructions.

**⚠ CAUTION** You CAN be HURT if you don't follow instructions.

- Instructions – how to service these products correctly and safely.

## OUTLINE OF CHANGES

### SPECIFICATIONS

1

### SERVICE INFORMATION

2

### MAINTENANCE

3

### TROUBLESHOOTING

4

### FUEL SYSTEM

5

### GOVERNOR SYSTEM

6

### GENERATOR SYSTEM

7

### IGNITION SYSTEM

8

### STARTING SYSTEM

9

### OTHER ELECTRICAL

10

### MUFFLER

11

### GENERATOR/ENGINE REMOVAL/INSTALLATION

12

### CYLINDER HEAD

13

### CRANKCASE

14

### WIRING DIAGRAMS

15









## INDEX

The marked sections contain no changes.  
They are not covered in this supplement.


## How to use this manual

# SYMBOLS

The symbols used throughout this manual show specific service procedures. If supplementary information is required pertaining to these symbols, it will be explained specifically in the text without the use of the symbols.

	Replace the part(s) with new one(s) before assembly.
	Use the recommended engine oil, unless otherwise specified.
	Use molybdenum oil solution (mixture of engine oil and molybdenum grease in a ratio of 1:1).
	Use multi-purpose grease (lithium based multi-purpose grease NLGI #2 or equivalent).
	Use marine grease (water resistant urea based grease).
	Apply a locking agent. Use a medium strength locking agent unless otherwise specified.
	Apply sealant.
	Use automatic transmission fluid.
(O x O) (O)	Indicates the diameter, length, and quantity of metric bolts used.
page 1-1	Indicates the reference page.

# OUTLINE OF CHANGES

Item	After	Before
Control panel (SK type)	 <p>Diagram illustrating the assembly of the control panel (SK type) components. The components shown are:</p> <ul style="list-style-type: none"><li>SCREW (3 x 3.8 mm) (2)</li><li>CONTROL WIRE HARNESS</li><li>VOLT METER</li><li>NUT (3 mm) (2)</li><li>SET PLATE</li><li>RECEPTACLE PACKING</li><li>AC OUTPUT RECEPTACLE (16A - 250 V)</li><li>SCREW (4 x 12 mm) (4)</li></ul>	

---

## MEMO

SPECIFICATIONS ..... 1-2      PERFORMANCE CURVES ..... 1-3

## SPECIFICATIONS

## SPECIFICATIONS

### DIMENSIONS AND WEIGHTS

Model	ER2500CX
Type	SK
Description code	ECCC
Overall length	591 mm (23.3 in)
Overall width	432 mm (17.0 in)
Overall height	462 mm (18.2 in)
Dry weight	40.0 kg (88.2 lbs)
Operating weight	51.1 kg (112.7 lbs)

### ENGINE

Model	GP160H
Description code	GCASH
Type	4 stroke, overhead valve, single cylinder, inclined by 25°
Displacement	163 cm <sup>3</sup> (9.9 cu-in)
Bore x stroke	68.0 x 45.0 mm (2.68 x 1.77 in)
Compression ratio	8.5 : 1
Ignition system	Transistorized magneto
Ignition timing	B.T.D.C. 25° / 1,400 min <sup>-1</sup> (rpm)
Recommended spark plug	BPR6ES (NGK)/W20EPR-U (DENSO)
Lubrication system	Forced splash
Oil capacity	0.58 Liter (0.61 US qt, 0.51 Imp qt)
Recommended oil	SAE 10W-30 API service classification SE or higher
Cooling system	Forced air
Starting system	Recoil starter
Stopping system	Ignition primary circuit ground
Carburetor	Horizontal type, butterfly valve
Air cleaner	Semi dry type
Governor	Centrifugal weight system
Breather system	Flat valve type
Fuel used	Unleaded gasoline

### GENERATOR

Model	ER2500CX
Type	SK
Description code	ECCC
Generator type	Double electrode field rotation type
Excitation	Self-excitation
Voltage regulation system	Transistor AVR (Automatic Voltage Regulator)
Phase	Single phase
Rated output	2.3 kVA
Rated frequency	60 Hz
Rated voltage	220 V
Rated current	10.5 A
Power factor	1.0 Cosθ

## CHARACTERISTICS


Model		ER2500CX
Type		SK
Voltage variation rate	Momentary	15% max.
	Average	7% max.
	Average time	5 sec. max.
Voltage stability		$\pm 1\%$ within
Frequency variation rate	Momentary	15% max.
	Average	7% max.
	Average time	5 sec. max.
Frequency stability		$\pm 1$ Hz within
Insulation resistance		10 M $\Omega$ min.
Circuit protector		11 A
Insulation type		Type F
Fuel tank capacity		14.5 ℓ (3.83 US gal, 3.19 Imp gal)
Fuel consumption at rated load		1.56 ℓ (0.412 US gal, 0.343 Imp gal) /Hr.
Max. operating hours at rated load		9.3 Hr.
Guaranteed sound power level (L <sub>WA</sub> ) at rated load		L <sub>WA</sub> 97 dB

## PERFORMANCE CURVES

- The curve shows performance of the generator under average conditions.
- Performance may vary to some degree depending on ambient temperature and humidity.
- The output voltage will be higher than usual when the generator is still cold, immediately after the engine starts.

### SK type

#### AC EXTERNAL CHARACTERISTIC CURVES





---

## MEMO

---

MAINTENANCE STANDARDS ..... 2-2      HARNESS AND TUBE ROUTING ..... 2-3

TORQUE VALUES ..... 2-2

## SERVICE INFORMATION

# MAINTENANCE STANDARDS

## ENGINE

Part	Item	Standard	Service limit
Engine	Engine speed (60 Hz)	$3,750 \pm 150 \text{ min}^{-1}$ (rpm)	—

## ELECTRICAL PARTS



Part		Connector	Terminal number	Standard
Main winding	SK type	①	2 – 4	$1.2 - 1.6 \Omega$ (at $20^\circ\text{C}/68^\circ\text{F}$ )
Exciter winding	SK type	②	1 – 2	$2.5 - 3.2 \Omega$ (at $20^\circ\text{C}/68^\circ\text{F}$ )

# TORQUE VALUES


## FRAME

Item	Thread Dia. (mm)	Torque values			Remark
		N·m	kgf·m	lbf·ft	
Volt meter mount nut	M3 nut	0.25	0.03	0.2	
Volt meter terminal screw	M3 screw	0.4	0.04	0.3	
Receptacle mount screw	M4 screw	1.3	0.1	1.0	

# HARNESS AND TUBE ROUTING




Terminal number	Wire color
2	R
4	Bu




Terminal number	Wire color
1	Y
2	Y
3	Bu
4	Br

Terminal number	Wire color
(C1)	Bu
(C2)	Y



Terminal number	Wire color
2	R
4	Bu




Terminal number	Wire color
1	Y
2	Y
3	Bu
4	Br

Terminal number	Wire color
(GND1)	Y/G


Bl	Black	Br	Brown
Y	Yellow	O	Orange
Bu	Blue	Lb	Light blue
G	Green	Lg	Light green
R	Red	P	Pink
W	White	Gr	Gray

SERVICE INFORMATION

SK TYPE



Terminal number	Wire color
T1	R
T2	R
T3	Bu
T4	Y/G
T5	R
T6	Bu
T7	R



Terminal number	Wire color
GND2	Y/G

Bl	Black	Br	Brown
Y	Yellow	O	Orange
Bu	Blue	Lb	Light blue
G	Green	Lg	Light green
R	Red	P	Pink
W	White	Gr	Gray

GOVERNOR ARM/CONTROL BASE REMOVAL/INSTALLATION .....	6-2
GOVERNOR ADJUSTMENT .....	6-3

## GOVERNOR SYSTEM

# GOVERNOR ARM/CONTROL BASE REMOVAL/INSTALLATION


Remove the fuel tank (base manual 82Z4100: page 5-3).

After installation, adjust the no load engine speed (page 6-3).

### GOVERNOR ROD/ANTI-SURGE SPRING

#### REMOVAL/INSTALLATION:

Remove the governor arm to a point where the groove [1] of the throttle arm lines up with the governor rod [2], and then lift the governor rod out of the hole of the throttle arm and unhook the anti-surge spring [3].



GOVERNOR ARM BOLT

NUT (6 mm)

BOLT (6 x 12 mm) (2)

GOVERNOR ARM

CONTROL BASE

SPRING

ADJUSTING SCREW

#### INSTALLATION:

##### SK type:

Hook the governor spring to the hole marked "1". Tighten the governor arm nut to more than 3.0 N·m (0.3 kgf·m, 2.2 lbf·ft), and then make sure that the clearance is more than 0.5 mm (0.02 in).

More than 0.5 mm (0.02 in)

SK type  
(60 Hz)

NUT (6 mm)

## GOVERNOR ADJUSTMENT

Remove the fuel tank (base manual 82Z4100: page 5-3).

Loosen the 6 mm nut [1] and move the governor arm [2] to fully open the throttle [3].


Rotate the governor arm shaft [4] as far as it will go in the same direction the governor arm moved to open the throttle and tighten 6 mm nut.

Install the fuel tank. Start the engine and allow it to warm up to normal operating temperature.

Check the engine no load maximum speed. Adjust by turning the adjusting screw [5] if necessary.

**Engine speed (at no load):**

**SK type (60 Hz):**  $3,750 \pm 150 \text{ min}^{-1} (\text{rpm})$





---

## MEMO

# 7. GENERATOR SYSTEM


---

GENERATOR SYSTEM TROUBLESHOOTING .....	7-2	MAIN WINDING INSPECTION .....	7-10
		EXCITER WINDING INSPECTION .....	7-10

## GENERATOR SYSTEM


# GENERATOR SYSTEM TROUBLESHOOTING

SK type:



# No AC Output

Before troubleshooting, make sure that the circuit breaker is in the ON position.




From page 7-3



Disconnect the exciter winding 4P connector (2).  
Check for continuity and insulation between the stator windings and the stator core using multimeter in minimum range.

No continuity or  
faulty insulation


Replace the stator (base manual  
82Z4100: page 7-10).



		Main winding		Exciter winding		Stator core
		Red	Blue	Yellow	Yellow	
Stator core		∞	∞	∞	∞	
Exciter winding	Yellow	∞	∞	Continuity		
	Yellow	∞	∞			
Main winding	Blue	Continuity				
	Red					

- See the main winding standard resistance on page 7-10.
- See the exciter winding standard resistance on page 7-10.

Normal




Go to page 7-5

From page 7-4

Disconnect the brush terminals, and remove the brush holder [1]. Clean and inspect the slip rings. Check the rotor resistance at the slip rings.

RESISTANCE: 31 - 39  $\Omega$  (20°C/68°F)

Measure the brush length (base manual 82Z4100: page 7-16).



Abnormal  
resistance

Replace the stator (base manual 82Z4100: page 7-10).

Normal


Disconnect the exciter winding 4P connector

(2).

Disconnect the brush terminals ((C1) and (C2)).

Start the engine, measure the voltage between Yellow and Yellow terminals of the exciter winding 4P connector (C2).

STANDARD VOLTAGE: 2 - 3 VAC




No or low voltage


Normal

Go to page 7-6

Go to page 7-6



## Low or high AC Output





From page 7-7



Disconnect the following:

- Main winding 4P connector (1).
- Exciter winding 4P connector (2).

Check for continuity and insulation between the stator windings and the stator core using multimeter in minimum range.

1

2

		Main winding		Exciter winding		Stator core
		Red	Blue	Yellow	Yellow	
Stator core		∞	∞	∞	∞	
Exciter winding	Yellow	∞	∞	Continuity		
	Yellow	∞	∞			
Main winding	Blue	Continuity				
	Red					

- See the main winding standard resistance on page 7-10.
- See the exciter winding standard resistance on page 7-10.


No continuity or faulty insulation

Replace the stator (base manual 82Z4100: page 7-10).

Normal



Faulty AVR unit.  
Replace the AVR unit (base manual 82Z4100: page 7-10).


**Generator will not deliver rated out put**

## MAIN WINDING INSPECTION

Remove the generator end cover (base manual 82Z4100: page 7-9).

Start the engine and measure the AC voltage between the main winding 4P connector (1) terminals with connector disconnected.


Type	Terminal No. (Color)	Voltage (About)
SK	No.2 (Red) and No.4 (Blue)	220 VAC



If the specified voltage is not obtained, stop the engine and measure the resistance between the main winding 4P connector (1) stator side terminals.

Type	Terminal No. (Color)	Resistance (at 20 °C/ 68 °F)
SK	No.2 (Red) and No.4 (Blue)	1.2 – 1.6 Ω

If the specified resistance is zero or infinity, replace the stator.




## EXCITER WINDING INSPECTION

Remove the generator end cover (base manual 82Z4100: page 7-9).

Disconnect the field winding connector (C1) and field winding connector (C2).

Start the engine and measure the AC voltage between the exciter winding 4P connector (2) No.1 (Yellow) terminal and No.2 (Yellow) terminal with connector disconnected.


**Standard voltage: About 2 – 3 VAC**



If the specified voltage is not obtained, stop the engine and measure the resistance between the exciter winding 4P connector (2) stator side No.1 (Yellow) terminal and No.2 (Yellow) terminal.

Type	Resistance (at 20 °C/68 °F)
SK	2.5 – 3.2 Ω

If the specified resistance is zero or infinity, replace the stator.




# 10. OTHER ELECTRICAL

---

CONTROL PANEL DISASSEMBLY/ ASSEMBLY .....	10-2
VOLT METER INSPECTION .....	10-3

# CONTROL PANEL DISASSEMBLY/ASSEMBLY

SK TYPE




## VOLT METER INSPECTION

Output voltage is normal but volt meter needle does not swing:

Start the engine and check whether there is voltage at the volt meter terminal.

**Rated voltage: 220 VAC**

If there is no specified voltage at terminal, replace the volt meter.



---


## MEMO

SK TYPE ..... 15-2



WIRING DIAGRAM

SK TYPE



CONTROL PANEL DISASSEMBLY/ASSEMBLY .....	10-2	MAIN WINDING INSPECTION .....	7-10
EXCITER WINDING INSPECTION .....	7-10	MAINTENANCE STANDARDS .....	2-2
GENERATOR SYSTEM TROUBLESHOOTING .....	7-2	PERFORMANCE CURVES .....	1-3
GOVERNOR ADJUSTMENT .....	6-3	SPECIFICATIONS .....	1-2
GOVERNOR ARM/CONTROL BASE REMOVAL/		TORQUE VALUES .....	2-2
INSTALLATION .....	6-2	VOLT METER INSPECTION .....	10-3
HARNESS AND TUBE ROUTING .....	2-3	WIRING DIAGRAM (SK TYPE) .....	15-2