

BRUSH CUTTER

UMK435T

PARTS CATALOGUE

4



UMK435T
(UMT TYPE)

FOREWORD INDEX

1

ENGINE GROUP

2

FRAME GROUP

3

PART NUMBER INDEX

4

PART NAME INDEX

5

Instruction for use of parts catalogue

- **This parts catalogue was prepared based on the latest information available as of December 10, 2013.**
- See the parts catalogue news for any revision that is made after December 10, 2013.
- **Always specify the part number when ordering a part.**
 - Check the model, type, serial numbers, color, maker, and the size as needed before ordering a part.
 - Note that the illustrations (part drawings) can differ from the actual parts in shape.
They are given just to help you to refer to the parts.
- **When modifications or additions to this parts catalogue are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers on the cover. We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your Honda distributor.**


Initial version issue date August 10, 2005
Honda Motor Co., Ltd.

CONTENTS

	Page	Address No.
● Instruction for use of parts catalogue	1	B 1
● How to refer to the part information	2	B 2
● Part catalogue structure	3	B 3
● When the parts were revised	4	B 4
● Abbreviations used in the parts catalogue	4	B 4
● How to check the part block and serial numbers	5	B 5
● Models, parts catalogue codes and applicable serial numbers	6	B 6
● Features of each type	7	B 7
● Fuel hose, general purpose hoses and vinyl hose	8	B 8
● FLAT RATE SERVICE TIME	9	B 9
● Illustrated index	14	B14
● ENGINE GROUP	18	D 1
● FRAME GROUP	34	E 1
● PART NO. INDEX	45	F 1
● PART NAME INDEX	47	G 1

How to refer to the part information

A Reference with "Illustrated index"



B Reference with "Part number index"

Part Number	Address	Page	Ref.	Part Number	Address	Page
06000				15212-ZW9-000	1-C14	3C
06316-ZW9-000	1-G9	88	1	15220-ZW9-003	1-C14	3C
11000				15332-ZW9-000	1-E8	55
11300-ZW9-405	1-C11	27	1	15332-ZW9-A30	1-E11	58
11300-ZW9-406	1-C11	27	1	15400-PFB-004	1-C11	27
11340-ZW9-000	1-C11	27	2	15422-ZW9-000	1-C14	3C
11342-ZW9-000	1-C11	27	3	15473-881-000	1-C14	3C
11381-ZW9-003	1-C12	28	1	15474-ZW9-000	1-C14	3C
				15611-921-000	1-C10	26
				15655-ZW9-000	1-C11	27
12000				16000		
12000-ZW9-405ZA	1-C11	27	4	16010-ZV4-005	1-D4	36
12155-ZV4-A00	1-C13	29	1	16011-ZV4-005	1-D4	36
12166-ZW9-000	1-C10	26	1	16013-ZW9-003	1-D4	36
12209-GB4-681	1-C16	32	1	16016-ZW9-003	1-D4	36
12210-ZW9-405ZA	1-C10	26	2	16016-ZW9-721	1-D4	36
12216-ZE2-300	1-E8	55	1	16023-ZW9-003	1-D4	36
	1-E11	58	1	16024-ZV4-650	1-D4	36
				16028-ZV4-650	1-D4	36

C Reference with "Part name index"

Partname	Address	Page	Ref.
[A]			
ABSORBER, FUEL	1-E15	62	5
ARMATURE COMP.	1-D11	43	7
ARM COMP., LINK JOINT	1-G6	85	18
ARM COMP., SHIFT LINK	1-G6	85	14
ARM COMP., TILT	1-F15	79	20
ARM, FUEL PUMP ROCKER	1-C16	32	4
ARM, REVERSE LOCK	1-F15	79	18
ARM, SHIFT LINK	1-F11	74	7
ARM, STOPPER	1-D1	33	12
ARM, THROTTLE REMOTE	1-F11	74	6
ARM, VALVE ROCKER	1-C16	32	3
[B]			
BAG, TOOL, 160MM	1-G5	84	10
BAND	1-G6	86	37
BAND B1, WIRE	1-F6	69	1
BAND, CORD	1-F3	67	18
BAND, TUBE CLIP, 11MM	1-E15	63	20
BAND, TUBE CLIP, 12.5MM	1-E15	63	19

Address No. 1-C10

Block No. E-2

Ref No.

Service item F.R.T.

Service item	F.R.T.
O-RING, 26X2.7	0.1
PLUG, SPARK	0.2
O-RING, 9.5X1.5	0.2
SENSOR ASSY., WATER TEMPERATURE	0.3
COVER COMP., HEAD	1.8
GASKET, CYLINDER HEAD	2.4
OIL SEAL, 20X32X6	3.1
HEAD COMP., CYLINDER	3.1

ZW93-50200

Ref. No.	Part No.	Description	Reqd. QTY						Serial No.	Parts catalogue code
			9901	9901	9901	1001	1001	1001		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2		
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1	1	1	1	1	1		
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1		
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1		
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1		
6	15611-921-000	CAP, OIL (NO GAUGE)	1	1	1	1	1	1		
7	16617-ZW9-000	HOLDER, CABLE	1	1	1	1	1	1	SC,SG	
	16617-ZW9-010		1	1	1	1	1	1	1001801	LHC,LHD
			1	1	1	1	1	1	1001801	LHC,LHD
8	35673-ZW5-003	SENSOR ASSY., WATER TEMPERATURE	1	1	1	1	1	1		
9	90003-ZW9-000	BOLT, FLANGE, 6X22	4	4	4	4	4	4		
10	90007-ZW9-003	BOLT, FLANGE, 8X83	6	6	6	6	6	6		
11	90011-ZW9-000	BOLT, FLANGE, 6X14 (CT200)	1	1	1	1	1	1		
12	90020-ZW9-000	BOLT, FLANGE, 8X40	2	2	2	2	2	2		
13	91202-KJ9-003	OIL SEAL, 20X32X6	1	1	1	1	1	1		
14	91301-805-000	O-RING, 26X2.7	1	1	1	1	1	1		
15	91307-PK2-005	O-RING, 9.5X1.5 (HONDA KIKAKI)	1	1	1	1	1	1		
16	98059-55916	PLUG, SPARK (CR5EH-9)	2	2	2	2	2	2		
	98059-55926	PLUG, SPARK (U16FER9)	2	2	2	2	2	2		

Page No.

2000.09.20 E

Part catalogue structure

E-2

CYLINDER HEAD

1-C10

Service item

F.R.T.

O-RING, 26X2.7		0.
PLUG, SPARK		0.
O-RING, 9.5X1.5		0.
SENSOR ASSY., WATER		0.
COVER COMP., HEAD		0.
PACKING, HEAD COVER		1.
GASKET, CYLINDER HEAD		2.
OIL SEAL, 20X32X6		3.
HEAD COMP., CYLINDER		3.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			BF BFP BF BFP BF BFP		
			9/9D1 9/9D1 10D1 10D1 10B1 10B1		
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER	1	1	1
		NHS.....DARK GRAY	1	1	1
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1
6	15611-921-000	CAP, OIL	1	1	1
		(NO GAUGE)	1	1	1
7	16617-ZW9-000	HOLDER, CABLE	1	1	1
	16617-ZW9-010		1	1	1

----- SC,SG
 1001800 LHC,LHD

E-14-10 **THROTTLE ROD** **1-C10/**

Service item F.R.T.

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			BF BFP BF BFP BF BFP		
			9/9D1 9/9D1 10D1 10D1 10B1 10B1		
15		CAM, THROTTLE (INC. RELATIVE PART)	0.2		
16		LINKAGE, PIVOT	0.3		
17		ROD COMP., THROTTLE			
		DIAPHRAGM ASSY.			

① Address number

- Address No. is provided (in place of the page No.) to help you refer to the part with the part No. or part name.

② Block title ③ Block number

④ Service item/Flat rate time

⑤ Reference number

- Title number marked with the parenthesis or parentheses indicates that it continues from the previous page.

⑥ Part number ⑦ Honda color code

⑧ Description

⑨ Assemblies

- Sections framed with broken lines in the exploded view drawings are available as complete assemblies. (Their individual parts can also be obtained.)

⑩ Color description

⑪ Note

- Notes are shown with the parentheses in the part name column.

⑫ Required quantity

- Required QTY shown in the parenthesis or parentheses indicates the optional part.
- Required QTY marked with "N" Indicates the optional part that should be selected as needed.
- Required QTY indicates the number of the part used in the block.

⑬ Serial number

⑭ Type

- When the type column is blank, it indicates that the part is applicable to all types.
- As the type of the actual unit may differ from the "parts catalogue, type" please refer to "Models, types and applicable serial numbers" for confirmation.

⑮

- Parts enclosed within a dotted line are covered in a different block.

⑯

- A hollow arrow indicates the block No. for the parts enclosed within a dotted line .

⑰

- A solid arrow indicates the block No. the part in question is connected to.

When the parts were revised



Be sure to check the serial number!!



Ref. No.	Part No.	Description	Reqd. QTY						Serial No.
			BF 99D1	BFP 99D1	BF 10D1	BFP 10D1	BF 10B1	BFP 10B1	
1	12166-ZW9-000	STOPPER, ENGINE SIDE	2	2	2	2	2	2	
2	12210-ZW9-000ZA	HEAD COMP., CYLINDER							
		NH8	1	1	1	1	1	1	
3	12251-ZW9-003	GASKET, CYLINDER HEAD	1	1	1	1	1	1	
4	12310-ZW9-000	COVER COMP., HEAD	1	1	1	1	1	1	
5	12312-ZW9-000	PACKING, HEAD COVER	1	1	1	1	1	1	
6	15611-921-000	CAP, OIL (NO GAUGE)	1	1	1	1	1	1	
7	16617-ZW9-000	HOLDER, CABLE (###)	1	1	1	1	1	1	
	16617-ZW9-010		1	1	1	1	1	1	

The number has been used from the initial model without revision.

When shown at the left side, it is applicable to the models of No.1001801 and the subsequent numbers.

When shown at the right side, it is applicable to the models up to No.1001800.





- The parts listed with "###" at the end of the parts name have limited supply period (parts not for sale).

Abbreviations used in the parts catalogue

- The following abbreviations are used in the parts name column.

A Ampere	FR.Front
A.C. Alternating current	IN.Inlet
ASSY. Assembly	L (100L) .Link (100 Links)
AT. Automatic transmission	L.Left
C.D.I. Capacitive discharge ignition	MMMillimeter
COMP. ... Complete	MT.Manual Transmission
D.C. Direct current	P.T.O.Power take off
EX. Exhaust	R.Right
G.F.C.I ... Ground fault circuit interruptor	RR.Rear
HEX. Hexagonal	STD.Standard
H.S.T. Hydrostatic transmission	T (22T) ...Tooth (22 Teeth)
	VVolt
	WWatt

How to check the part block and serial numbers



Models, parts catalogue codes and applicable serial numbers

- Models, parts catalogue codes and applicable serial Nos. given in this parts catalogue can be identified as follows.

Model	Type	Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.	Applicable carburetor identification No.
			Model	Type			
UMK435T	U2ST	U2ST	GX35T	GY7	GCAMT-1000001~	HAAT-1000001~	WYB 14B
	U2T	U2T	GX35	GY5	GCACM-1100001~ 9999999	HAAT-1000001~ 9999999	
	U2TT	U2TT	GX35T	GY7	GCAMT-1000001~	HAAT-1000001~	
	UMST	UMST					
	UMT	UMT	GX35	GY5	GCACM-1100001~ 9999999	HAAT-1000001~ 9999999	
	UMTT	UMTT	GX35T	GY7	GCAMT-1000001~	HAAT-1000001~	
	U2BT	U2BT		GY3			
	U2NT	U2NT		GD7			
	UEDT	UEDT		GY2			
	UENT	UENT		GY9			
	UERT	UERT		GY2			

* Of carburetor identification numbers, only the portions underlined in the example below are used for registration.

WYB 14B

Features of each type

- See the following table for the features of each type. (Items in brackets are optional)

Model Type		UMK435T										
		U2ST	U2T	U2TT	UMST	UMT	UMTT	U2BT	U2NT	UEDT	UENT	UERT
Tank guard								●	●	●	●	●
Cutter blade	2-Teeth	●	●	●				●	●			
	3-Teeth									●	●	●
	Mowing cutter				●	●	●					
	Nylon cutter									●	●	●

Fuel hose, general purpose hoses and vinyl hose

- The standard part fuel hose, general purpose hose and vinyl hose may be substituted by the coiled bulk part.
- When ordering the standard part fuel hose, general purpose hose and vinyl hose use the bulk part number written in the parts catalog in brackets () underneath the part name.
- When exchanging the hose, cut and use at the specified length as mentioned in the part name.
(For the method of cutting the bulk part, and method of filling out orders etc., please refer to the instructions issued with the bulk part.)

Bulk part number of fuel hose, general purpose hose and vinyl hose.

Example: 9 5 0 0 1 - 7 5 0 0 1 - 5 0 M

Bulk part number:

Refers to the bulk part.

Marking code (fuel hose and general purpose hose)

Change code (Vinyl hose)

Indicates number mark or change sequence, however, the code for the bulk part must be strictly 0 (zero).

Types of code:

- Fuel hose
 - 2: Red outside braid (3 mm inside dia. only)
 - 5: Black inside braid
 - 3: Red (3 mm inside dia. only)
 - 4: Ash gray with red stripe (3 mm inside dia. only)
 - 6: Black

- General hose
 - 1: Ash gray
 - 2: Ash gray
 - 3: Black
 - 5: Black

- Vinyl hose
 - 1: Clear
 - 2: Black
 - 3: Light red
 - 6: Light red
 - 7: Pale black

Lengths:

001: 1 m (standard)
003: 3 m
008: 8 m

} Application or specification of some parts is not settled.

I.D code: (fuel hose and general purpose hose)

30: 3.0 mm
35: 3.5 mm
45: 4.5 mm

50: 5.0 mm
55: 5.3 mm, 5.5 mm
65: 6.5 mm

70: 7.0 mm
75: 7.3 mm, 7.5 mm
80: 8.0 mm

11: 11 mm
91: 12 (outside dia. 15) mm
92: 12 (outside dia. 16) mm

12: 12 (outside dia. 17) mm
14: 14 mm
17: 17 mm

ID./OD. code: (vinyl hose)

01: ID. 2.9, OD. 6.8 mm
03: ID. 3.0, OD. 6.0 mm
05: ID. 3.5, OD. 6.5 mm
07: ID. 4.0, OD. 7.0 mm
08: ID. 4.5, OD. 6.5 mm
09: ID. 4.5, OD. 8.0 mm

12: ID. 5.0, OD. 7.0 mm
10: ID. 5.0, OD. 8.0 mm
11: ID. 5.0, OD. 9.0 mm
14: ID. 6.0, OD. 9.0 mm
17: ID. 7.0, OD. 9.0 mm
19: ID. 7.0, OD. 11.0 mm

21: ID. 8.0, OD. 9.0 mm
23: ID. 8.0, OD. 12.0 mm
25: ID. 9.0, OD. 11.0 mm
27: ID. 9.0, OD. 13.0 mm
33: ID. 10.0, OD. 14.0 mm
36: ID. 11.0, OD. 13.0 mm

37: ID. 11.0, OD. 15.0 mm
38: ID. 12.0, OD. 13.0 mm
39: ID. 12.0, OD. 14.0 mm
40: ID. 12.0, OD. 16.0 mm
43: ID. 13.0, OD. 15.0 mm
45: ID. 14.0, OD. 18.0 mm

50: ID. 16.0, OD. 19.0 mm
55: ID. 17.5, OD. 20.5 mm
60: ID. 22.0, OD. 27.0 mm

Hose type:

- 1: Fuel hose
- 3: Vinyl hose
- 5: General hose


⊙ **CAUTION:** It is **DANGEROUS** to confuse the fuel hose with the general purpose hose or vinyl hose.

Never use a general purpose hose or vinyl hose in place of a fuel hose or vice versa. Always use the correct bulk part in the parts catalogue, according to the service manual or the instructions issued with the bulk part.

FLAT RATE SERVICE TIME

Flat rate service time (FRT) means the standard time required to service a product, which is listed in this manual to help the dealers control the actual working process and calculate the service charge by using it as a guide.

FRT setting system



* Float time is set by multiplying the net service time by a given coefficient.

Editorial style

The service items shown in the text are listed with the exchange work time for the repair sales parts as the subject. Other representative service items not using repair parts (removal/installation, adjustment, inspection/measuring, and other work) are listed collectively in the list in the preface, classified according to the work.

FRT setting standard

- Decimal system (in unit of 0.1) is adopted to set FRT as it is convenient to calculate the wage.
Example: (0.1) → 6 minutes, (0.2) → 12 minutes
[Labor cost per hour] x [FRT] = [Wage]
- FRT is set with a hand tool.
- Service items and FRT can be subject to change depending on development of tools and service equipment and improvement in service procedure.

Work procedure

- As the work procedure is set with the work time according to the method in the separate Service Manual, refer to this Manual as required.
- Work methods permitting servicing in the shortest time still permitting assurance of safe work and product warranty are used for the setting of service items not listed in the Service Manual.
- Work basically is to be performed by one person, and when two or more people are required, setting is done as the total time for the number of people.
- The set value for the technological level of the workers uses a person with three years of experience in the repair of Honda products as the standard.
- Special tools and service equipment used to set FRT are those specified or recommended in Service Manual.

Service item whose FRT is not presented

- Accessories and service parts that are not listed to use in this manual.
- Locations with little aging deterioration or breakage during normal use.
- Service work that can be finished by one touch.
- Service work that is seldom done (i.e. extremely small causes of trouble and service frequency).
- Products and parts whose location for installation differs according to its status of use and application.

* When FRT is not presented, please calculate wages based on appropriate actual work time.

Operation not included of FRT

- Oil and coolant water draining, Waiting time for warming up operation and etc..
- Additional operation that involves removal/installation of standard exterior equipment.
- Indirect time spent for service by visiting the customer, trade-in, and delivery.
- Indirect time required for ordering and delivery of parts.
- Cost for grease, adhesive agent, etc. used for service work.

Explanation of FRT by using an example
(The example may differ from the actual presented items)

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
① ②	1111L1	(1, 3, 4, 7) VALVE, INTAKE 4.1	②
③	1111L1A	• NOTE: OHV type • Includes: Engine removal and installation One head (intake all) add 1.4	⑦ ⑤

- ① Reference No. of the illustration of part that shows location of the replacement work.
- ② FRT is an abbreviation of Flat Rate Time indicating the standard service time required for the replacement.
- ③ LON is an abbreviation of Labor Operation Number, and it is a classification of the service items by the work unit code.

The same operation code is used regardless of the models.

Standard operation is indicated with 6 digits code, and additional operation is indicated with 7 digits code.


- ④ Indicating the intake valve replacement and FRT4.1.
- ⑤ Indicating FRT1.4 that will be added when additional operation (whole intake side of one cylinder head) is done in association with intake valve replacement.

- ⑥ Indicating work condition or application condition of the service item.
- ⑦ Indicating work contents that are included in the service item.
- ⑧ Indicating a reference No. whose operation and time are the same as FRT4.1 for the intake valve.

(The application range is limited to the service items without an LON setting within a same block.)

How to refer to the service item by using the sample
 (intake valve replacement)

Open to the page of the block where the intake valve's spare part illustration is shown.



Look for the intake valve illustration, and refer to the service item and FRT that agree with the reference No.

Indication mark for the listing of service items that continues to the following page

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2	1111L1	VALVE, INTAKE	4.1
	.	.	.
	.	.	.

+

Mark indicated at the last line.

Indication of the block with no setting of FRT

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
NO INFORMATION			

• LON code system

1	11	1	L1	A
a	b	c	d	e

- a) Category code..... Engine
- b) Location/function code..... Engine upper
- c) Operation code..... Replace
- d) Operation sequence number (Unit code can be shown with alphabet)
..... Intake valve
(No regular rule of code)
- e) Additional code One head (intake all)
(No regular rule of code)

1	11	1	L1	A
a		c		

a) Category codes and classification

Code	Category
1	Engine
2	Power drive
3	Fuel & Exhaust
4	Frame & Body
5	Steering
6	Electrical
7	Axle & Brake
8	Control system
9	-
0	Attachments

c) Operation codes and classification

Code	Operation category
1	Replace, Removal/Installation, Change
2	Overhaul
3	Adjust, Rotation
4	(Paint-related work: Top-coat)
5	Test, Inspect/diagnose, Measurement
6	(Overhaul-related work: Rebore)
7	(Overhaul-related work: Reseal)
8	(Resurface)
9	(Paint-related work: Refinish)
0	Repair, Cleaning, Air bleeding

Major service items without using spare parts

(1) Removal/Installation, (2) Adjustment,
(3) Inspection/Masurement, (4) Overhaul, (5) Other work

E: Engine, T: Transmission, D: Drive system,

B: Body and related parts

(1) Removal/Installation

Set with the parts configuration in the status of being removed from the product.

	LON	DESCRIPTION	FRT
E	1001A2	ENGINE-REMOVAL/INSTALLATION	0.2

(2) Adjustment

	LON	DESCRIPTION	FRT
E	1113A1	VALVE CLEARANCE-ADJUSTMENT NOTE: For 1 product	0.4
	3113A2	CARBURETOR IDLE-ADJUSTMENT	0.2
	8113B1	THROTTLE CABLE-ADJUSTMENT	0.1

(3) Inspection, Measurement, Cleaning

	LON	DESCRIPTION	FRT
E	1105A0	ENGINE OIL-INSPECTION	0.1
	3120A0	AIR CLEANER-CLEANING INCLUDES: Air cleaner-inspection	0.1
	6140A0	SPARK PLUG-ADJUSTMENT/CLEANING INCLUDES: Spark plug check NOTE: For 1 product	0.1
B	2165A0	BLADE CUTTER-INSPECTION	0.1

(4) Overhaul

Work condition: The required Measurements, inspections, adjustments, and cleaning/washing of each part are performed, including the main body removal/installation work and the replacement of defective parts.

	LON	DESCRIPTION	FRT
E	3112A0	CARBURETOR-OVERHAUL INCLUDES: All necessary adjustment	0.4

(5) Other work

	LON	DESCRIPTION	FRT
E	1101E1	ENGINE OIL-CHANGE INCLUDES: Engine oil-inspection	0.1


ENGINE GROUP

B14

E-2

CRANKCASE SET


D 1



E-7

CRANKSHAFT/PISTON


D 3



E-10

CAMSHAFT PULLEY


D 4



E-11

RECOIL STARTER


D 6



E-12

FAN COVER/CLUTCH


D 7



E-14

CARBURETOR


D 8



E-15

AIR CLEANER(1)


D10



E-15-1

AIR CLEANER(2)


D11



E-16

MUFFLER

D12




ENGINE GROUP

B15

E-17

D13


FUEL TANK



E-19

D14


FLYWHEEL



E-27

D15


TOP COVER



E-28

D16

LABEL



2


FRAME GROUP

B16

F-1

E 1


HANDLE PIPE/THROTTLE LEVER(1)



F-1-1

E 2


HANDLE PIPE/THROTTLE LEVER(2)



F-2

E 3


GEAR CASE(1)



F-2-1

E 4


GEAR CASE(2)



F-3

E 5


FRAME



F-4

E 6


BLADE(1)



F-4-1

E 7


BLADE(2)



F-28

E 8


LABEL



F-29

E 9

TOOL




FRAME GROUP

C 1

F-40

E10


SHOULDER BELT



F-40-1

E11


NYLON CUTTER



E-2

CRANKCASE SET

D 1




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1101B7	CRANKCASEINCLUDES: Engine removal and installation (3)	1.7
2	1111D5	CYLINDER HEAD COVER AND/OR PACKING	0.1
6	1111A2	ARM, ROCKER :INTAKEINCLUDES: Valve clearance adjustment	0.6
7	1111A1	ARM, ROCKER :EXHAUSTINCLUDES: Valve clearance adjustment	0.6
8	1111L9	LIFTER, VALVE :INTAKEINCLUDES: Valve clearance adjustment	0.6
9	1111M0	LIFTER, VALVE :EXHAUSTINCLUDES: Valve clearance adjustment	0.6
10	1171A4	TUBE, OIL (12,29)	0.4
11	1171A2	PLATE, OIL OUTLET VALVEINCLUDES: Engine removal and installation	1.3
16	1111K5	TUBE, BREATHER	0.1
+17	6141C1	PLUG, SPARK	0.1

Ref. No.	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
1	10100-Z3F-405	CRANKCASE SET	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	10100-Z0Z-405		1	1183074	U2T,UMT
	10100-Z3F-405		1	1183075	U2T,UMT
2	12310-Z0Z-000	COVER, CYLINDER HEAD	1	-----	-----
3	12312-Z0Z-300	SEAL, HEAD COVER	1	-----	-----
4	12314-Z0H-300	GROMMET, HEAD COVER	1	-----	-----
5	12367-Z0H-000	FILTER, BREATHER	1	-----	-----
6	14431-Z0H-003	ARM, IN. VALVE ROCKER	1	-----	-----
7	14441-Z0H-003	ARM, EX. VALVE ROCKER	1	-----	-----
8	14730-Z0Z-000	LIFTER COMP., IN. VALVE	1	-----	-----
9	14740-Z0Z-000	LIFTER COMP., EX. VALVE	1	-----	-----
10	15422-Z0Z-000	TUBE, OIL	1	-----	-----
11	15510-Z0H-000	PLATE ASSY., OIL OUTLET VALVE	1	-----	U2T,UMT
12	15571-ZM3-003	VALVE, OIL OUTLET	1	-----	U2T,UMT
14	15600-Z3F-000	CAP ASSY., OIL FILLER	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	15600-ZM3-003		1	-----	U2T,UMT
15	15625-Z0T-800	PACKING, OIL FILLER CAP	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	15625-ZE1-003		1	-----	U2T,UMT
16	15721-Z0Z-000	TUBE, BREATHER	1	-----	-----
17	31914-Z0H-003	PLUG, SPARK(CMR4H)(NGK)	(1)	-----	-----
	31915-Z0H-003	PLUG, SPARK(CMR5H)(NGK)	1	-----	-----
	31916-Z0H-003	PLUG, SPARK(CMR6H)(NGK)	(1)	-----	-----
18	90009-Z0H-003	BOLT, SOCKET, 5X20	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	90009-Z3E-901		2	-----	U2NT,UENT,UERT
19	90010-Z0Z-003	BOLT, SOCKET, 5X32	4	-----	-----
20	90013-Z3E-003	SCREW, PAN, 4X8	2	-----	U2BT,U2NT,UEDT,UENT,UERT

E-2

CRANKCASE SET

D 2




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
+17		.INCLUDES: Spark plug check	
30	1101U0	CRANKCASE SET ASSEMBLY	1.6
		.INCLUDES: Engine removal and installation	

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
20)	90013-Z0H-004	SCREW, PAN, 4X8	2	-----	U2T,UMT
	90013-Z3E-003		2	1088910	U2ST,U2TT,UMST,UMTT
				1088911	U2ST,U2TT,UMST,UMTT
21	90013-Z3F-003	SCREW, PAN, 4X8	2	-----	U2BT,U2NT,UEDT,UENT,UERT
	90013-Z0Z-003		2	-----	U2T,UMT
				1088910	U2ST,U2TT,UMST,UMTT
	90013-Z3F-003		2	1088911	U2ST,U2TT,UMST,UMTT
22	90017-Z0H-000	SCREW, TAPPET ADJUSTING	2	-----	
23	90019-Z0H-003	BOLT, SOCKET, 5X12	2	-----	
24	90206-ZM3-000	NUT, TAPPET ADJUSTING	2	-----	
25	93500-03005-0A	SCREW, PAN, 3X5	1	-----	U2T,UMT
26	94305-40102	PIN, SPRING, 4X10	1	-----	
27	95002-41200-08	CLAMP, TUBE(D12)	1	-----	
28	95002-41300-04	CLAMP, TUBE(D13)	1	-----	
29	15510-Z3E-000	PLATE ASSY., OIL OUTLET VALVE	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
30	10100-Z3F-406	CASE SET ASSY., CRANK	1	-----	U2NT,U2ST,U2TT,UMST,UMTT


2

FR.



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1		(2,3)	
1111J4		RING SET, PISTON	1.5
		.INCLUDES: Engine removal and installation	
1111J4F		.Replace 1 piston and/or pin and/or connecting rod and/or bearing add	0.1
4	1101R3	CRANKSHAFT ASSEMBLY	1.4
		.INCLUDES: Engine removal and installation	
5	1101E5	OIL SEAL, CRANKSHAFT :REAR ...	1.4
		.INCLUDES: Engine removal and installation	
6	1101E4	OIL SEAL, CRANKSHAFT :FRONT ..	1.4
		.INCLUDES: Engine removal and installation	
7	1101F0	CRANKSHAFT	1.7
		.INCLUDES: Engine removal and installation	

Ref. No.	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
1	13010-ZM5-000	RING SET, PISTON	1		
2	13101-Z02-000	PISTON	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	13101-Z02-010		1	-----	U2NT,UENT,UERT
3	13111-ZM5-000	PIN, PISTON	1		
4	13310-Z02-000	CRANKSHAFT COMP.	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	13310-Z02-010		1	-----	U2NT,UENT,UERT
5	91212-Z3E-003	OIL SEAL, 10X20X5	1	-----	U2BT,U2NT,UEDT,UENT,UERT
	91212-Z0H-003		1	-----	U2T,UMT
	91212-Z3E-000		1	1088910	U2ST,U2TT,UMST,UMTT
	91212-Z3E-003		1	1088911	U2ST,U2TT,UMST,UMTT
6	91214-Z3F-003	OIL SEAL, 15X25X6	1	-----	U2BT,U2NT,UEDT,UENT,UERT
	91214-ZM3-003		1	-----	U2T,UMT
	91214-Z3F-000		1	1088910	U2ST,U2TT,UMST,UMTT
	91214-Z3F-003		1	1088911	U2ST,U2TT,UMST,UMTT
7	13310-Z02-305	CRANKSHAFT COMP.	(1)	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UMST,UMTT
	13310-Z3F-305		(1)	-----	UERT




VK98-E1000

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1111K2	SEAL, INTAKE VALVE STEMINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment	1.5
3	1111N5	PULLEY, CAMSHAFTINCLUDES: Engine removal and installation	0.6
4	1111N6	BELT, TIMINGINCLUDES: Engine removal and installation	1.4
5	1111L1	VALVE, INTAKEINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment and reface	1.5
	1111L1E	.Replace intake and exhaust all add	0.1
6	1111L0	VALVE, EXHAUSTINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment and reface	1.5
	1111L0E	.Replace intake and exhaust all add	0.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	12209-Z3E-003	SEAL, VALVE STEM	1	-----	U2BT,U2NT,UEDT,UENT,UERT
	12209-Z3E-000		1	-----	1088910 U2ST,U2TT,UMST,UMTT
	12209-Z0H-003		1	-----	1183074 U2T,UMT
	12209-Z3E-003		1	1088911	----- U2ST,U2TT,UMST,UMTT
	12209-Z3E-000		1	1183075	----- U2T,UMT
2	14126-Z0Z-003	ROLLER, 4X31.8	1	-----	-----
3	14320-Z0Z-000	PULLEY COMP., CAMSHAFT	1	-----	-----
4	14400-Z3F-003	BELT, TIMING(76ZU7 G-300) ...	1	-----	----- U2BT,UEDT
	14400-Z3F-013	BELT, TIMING(76ZU6 G-310) ...	1	-----	----- U2NT,UENT,UERT
	14400-Z0Z-003	BELT, TIMING(76ZU7 G-300) ...	1	-----	----- U2T,UMT
	14400-Z3F-003		1	1022910	----- U2ST,U2TT,UMST,UMTT
	14400-Z3F-003		1	1022911	----- U2ST,U2TT,UMST,UMTT
5	14711-Z0Z-800	VALVE, IN.	1	-----	----- U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	14711-Z3F-000		1	-----	----- UERT
	14711-Z0Z-000		1	1183074	----- U2T,UMT
	14711-Z0Z-800		1	1183075	----- U2T,UMT
6	14721-Z0Z-800	VALVE, EX.	1	-----	----- U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	14721-Z3F-000		1	-----	----- UERT
	14721-Z0Z-000		1	1183074	----- U2T,UMT
	14721-Z0Z-800		1	1183075	----- U2T,UMT
7	14751-Z0Z-000	SPRING, VALVE	2	-----	-----
8	14771-Z0H-000	RETAINER, VALVE SPRING	2	-----	-----


FR.



VK98-E1000


Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
7	1111P3	SPRING, VALVE :INTAKEINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment	1.5
	1111P3A	.Replace intake and exhaust all add	0.1
	1111P4	SPRING, VALVE :EXHAUSTINCLUDES: Engine removal and installation .INCLUDES: Valve clearance adjustment	1.5
	1111P4A	.Replace intake and exhaust all add	0.1

FR.



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1121B9	STARTER, RECOIL	0.2
3	1121B1	REEL, RECOIL STARTER	0.3
5	1121B7	SPRING, RECOIL STARTER RETURN	0.3
6	1121A9	PULLEY, RECOIL STARTER	0.5
		.INCLUDES: Engine removal and installation	
8	1121A3	GRIP, RECOIL STARTER	0.1
9	1121B3	ROPE, RECOIL STARTER	0.3

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	28400-Z0Z-003	STARTER ASSY., RECOIL	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	28400-Z3F-M01		1	-----	U2NT,UENT,UERT
2	28414-Z0Z-000	CASE, RECOIL STARTER	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	28414-Z3F-M01		1	-----	U2NT,UENT,UERT
3	28421-ZM3-003	REEL, RECOIL STARTER	1		
4	28433-ZM3-003	GUIDE, ROPE	1		
5	28442-Z0H-003	SPRING, RECOIL STARTER	1		
6	28451-Z0H-003	PULLEY, RECOIL STARTER	1		
7	28459-Z0H-003	ARM, SWING	1		
8	28461-ZM3-003	KNOB, RECOIL STARTER	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	28461-Z3F-M01		1	-----	U2NT,UENT,UERT
9	28462-ZM3-003	ROPE, RECOIL STARTER	1		
10	90012-ZM3-003	SCREW, SETTING	1		
11	90018-Z0H-003	BOLT, SOCKET, 5X16	1	-----	U2BT,UEDT
	90018-Z3E-901		1	-----	U2NT,UENT,UERT
	90018-Z0H-003		3	-----	U2ST,U2T,U2TT,UMST,UMT,UMTT
12	91504-ZM3-003	COLLAR	1		
13	91506-ZM3-000	COLLAR A, HEAD COVER	3		




Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	1141G8	COVER, ENGINE COOLING FANINCLUDES: Engine removal and installation	0.3
2	2121F7	CLUTCH, CENTRIFUGALINCLUDES: Engine removal and installation	0.5

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	19611-Z0Z-000	COVER, FAN	1		
2	22000-Z0Z-003	CLUTCH ASSY.(ACRO)	1		
	22000-Z3F-004	CLUTCH ASSY.(FCC)	1		
3	22253-Z3F-000	BOLT, CLUTCH(8MM)	2		
	22253-Z0Z-003		2		
4	22254-Z3F-000	WASHER, CLUTCH(8X17)	2		
	22254-ZM5-003		2		
5	22255-Z3F-000	WASHER, WAVE(10MM)	2		
	22254-Z0Z-003		2		
6	90009-Z0H-003	BOLT, SOCKET, 5X20	3		
	90009-Z3E-901		3		
				1373008	U2NT U2ST,U2TT,UMST,UMTT U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT U2T,UMT U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT U2T,UMT
					U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT U2NT,UENT,UERT

E-14


CARBURETOR

D 8



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2		(19,22)	
3111B7		GASKET, CARBURETOR PUMP	0.4
5		(4,7)	
3111A0		BODY ASSEMBLY, PUMP	0.4
6		(1,3)	
3111A1		BODY, AIR PURGE	0.3
8		3111E3 VALVE, INLET NEEDLE	0.4
21		3111D5 PUMP, PRIMER	0.3
23		3111F3 CARBURETOR	0.2
24		3111C8 PACKING, CARBURETOR	0.2
25		(29)	
4141E3		SHROUD, ENGINE	0.2
28		3111C7 O-RING, CARBURETOR BODY	0.1
30		(14)	
3111C3		JET, MAIN	0.4

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	16010-ZM3-004	GASKET, METERING DIAPHRAGM ..	1		
2	16011-ZOH-013	GASKET, PUMP	1		
3	16013-ZOH-003	DIAPHRAGM ASSY., METERING ...	1		
4	16014-ZM3-004	DIAPHRAGM, PUMP	1		
5	16015-Z3F-J42	BODY ASSY., PUMP	1	----- U2BT	
	16015-ZOH-013		1	----- U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT,UMST,UMT,UMTT	
6	16017-ZM3-004	BODY ASSY., AIR PURGE	1		
7	16018-ZM3-802	SCREEN, INLET	1		
8	16019-ZM3-004	VALVE, INLET NEEDLE	1		
9	16020-ZM3-004	SPRING, METERING LEVER	1		
10	16021-Z3F-J42	SCREW, METERING LEVER PIN ...	1	----- U2BT	
	16021-ZM3-004		1	----- U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT,UMST,UMT,UMTT	
11	16022-ZM3-014	PIN, METERING LEVER	1		
12	16023-ZM3-004	LEVER, METERING	1		
13	16024-ZOH-003	RING, RETAINING	1		
14	16025-ZM3-004	O-RING	1		
15	16026-ZM3-004	COVER, PRIMER PUMP	1		
16	16027-ZM3-004	SWIVEL	1		
17	16028-ZM3-004	SCREW, THROTTLE COLLAR	2		
18	16029-ZM3-004	SCREW, PUMP COVER	4		
19	16030-ZM3-004	SPRING, PUMP	1		
20	16031-ZM3-004	WASHER	1		
21	16032-ZM3-004	PUMP, PRIMER	1		
22	16035-ZM3-802	FILTER, FUEL INLET	1		
23	16100-Z3F-J42	CARBURETOR ASSY.(WYB 31)	1	----- U2BT	




Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
23)	16100-Z3F-K52	CARBURETOR ASSY.(WYB 38)	1	-----	U2NT,UENT
	16100-Z0Z-814	CARBURETOR ASSY.(WYB 14B) ...	1	-----	U2ST,U2T,U2TT,UMST,UMT,UMTT
	16100-Z0Z-815	CARBURETOR ASSY.(WYB 14D) ...	1	-----	UEDT,UERT
24	16221-Z0Z-000	PACKING, CARBURETOR	1		
25	19631-Z0Z-010	SHROUD	1		
26	90014-Z0H-003	BOLT, 5X53	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UERT,UMST,UMT,UMTT
	90014-Z3F-000	BOLT, 5X58	2	-----	U2NT,UENT
27	90018-Z0H-003	BOLT, SOCKET, 5X16	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	90018-Z3E-901		2	-----	U2NT,UENT,UERT
28	91301-ZM3-000	O-RING, 14.8X2.4	1		
29	91308-Z3E-000	O-RING, 12.3X2.4	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	91308-Z0H-003		1	-----	U2T,UMT
30	99101-Z0Z-0370	JET(#37)	(1)	-----	U2BT
	99101-Z0Z-0380	JET(#38)	1	-----	U2BT
	99101-Z0Z-0360	JET(#36)	(1)		
	99101-Z0Z-0370	JET(#37)	1	-----	U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT,UMST,UMT,UMTT
	99101-ZM5-0350	JET(#35)	(1)	-----	U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT,UMST,UMT,UMTT

E-15

AIR CLEANER(1)

D10

FR.



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	3121B8	ELEMENT, AIR CLEANERINCLUDES: Air cleaner element -inspection	0.1
2	3121A5	CASE, AIR CLEANER	0.1
3	3121B1	COVER, AIR CLEANER	0.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	17211-Z0Z-000	ELEMENT, AIR CLEANER	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UERT,UMST,UMT,UMTT
2	17220-Z0Z-000	CASE COMP., AIR CLEANER	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	17220-Z0Z-010		1	-----	UERT
3	17231-Z0Z-010	COVER, AIR CLEANER	1	-----	U2BT,UEDT,UERT
	17231-Z0Z-000		1	-----	U2ST,U2T,U2TT,UMST,UMT,UMTT
4	90009-Z0Z-003	BOLT, SOCKET, 5X25	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	90009-Z3F-901		1	-----	UERT
5	90018-Z0H-003	BOLT, SOCKET, 5X16	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	90018-Z3E-901		1	-----	UERT
6	94050-05000	NUT, FLANGE, 5MM	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UERT,UMST,UMT,UMTT
7	91501-Z0Z-000	COLLAR, AIR CLEANER CASE	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UERT,UMST,UMT,UMTT
8	91503-ZM3-000	COLLAR, AIR CLEANER	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UERT,UMST,UMT,UMTT
9	91506-ZM3-000	COLLAR A, HEAD COVER	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UERT,UMST,UMT,UMTT


2

E-15-1

AIR CLEANER(2)

D11

FR.



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2	3121B8	ELEMENT, AIR CLEANERINCLUDES: Air cleaner element -inspection	0.1
3	3121A5	CASE, AIR CLEANER	0.1
4	3121B1	COVER, AIR CLEANER	0.1


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	17204-Z3F-000	PLATE, OIL TRAP	1	-----	U2NT,UENT
2	17211-Z3F-000	ELEMENT, AIR CLEANER	1	-----	U2NT,UENT
3	17220-Z3F-000	CASE COMP., AIR CLEANER	1	-----	U2NT,UENT
4	17231-Z3F-000	COVER, AIR CLEANER	1	-----	U2NT,UENT
5	90009-Z3F-901	BOLT, SOCKET, 5X25	1	-----	U2NT,UENT
6	90018-Z3E-901	BOLT, SOCKET, 5X16	1	-----	U2NT,UENT
7	90102-Z07-003	SCREW, SPECIAL, 6X16	1	-----	U2NT,UENT
8	91501-Z3F-000	COLLAR, AIR CLEANER CASE(A) -	2	-----	U2NT,UENT
9	91502-Z3F-000	COLLAR, AIR CLEANER CASE(B) -	1	-----	U2NT,UENT
10	91503-Z3F-000	COLLAR, AIR CLEANER CASE(C) -	1	-----	U2NT,UENT
11	94050-05000	NUT, FLANGE, 5MM	2	-----	U2NT,UENT

E-16

MUFFLER

D12

FR.



VK98E1600A

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	3131C5	MUFFLER, EXHAUST	0.1
2	3131B6	GUIDE, AIR EXHAUST	0.1
3	3131G8	GUIDE, AIR EXHAUST :UNDER	0.1

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	18310-Z0Z-010	MUFFLER COMP.	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	18310-Z0Z-020		1	-----	U2NT,UENT,UERT
2	18515-Z0Z-300	GUIDE, AIR	1		
3	18518-Z0Z-020	GUIDE COMP., UNDER AIR	1		
4	90001-Z0Z-013	BOLT, STUD, 5X56.5	2	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	90001-Z0Z-003		2	-----	U2T,UMT
5	90018-Z0H-003	BOLT, SOCKET, 5X16	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	90018-Z3E-901		2	-----	U2NT,UENT,UERT
6	90136-SM4-901	NUT, SELF-LOCK, 5MM	2		
7	91506-ZM3-000	COLLAR A, HEAD COVER	2		


2

E-17

FUEL TANK

D13


FR.



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	3101J0	GROMMET, FUEL TUBE	0.2
2	3101H7	TANK, FUEL	0.2
4	3101M7	CAP, FUEL FILLER	0.1
5	3101A6	FILTER, FUEL	0.2
6		(17)	
7	3101F1	TUBE, FUEL TANK	0.2
		(15,16,18)	
	3101L8	TUBE, FUEL RETURN	0.2

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	17504-ZM3-003	GROMMET, FUEL TUBE	1		
2	17511-Z0Z-013	TANK, FUEL	1		
3	17533-Z0H-000	RUBBER, TANK MOUNTING	4		
4	17620-ZM3-817	CAP ASSY., FUEL TANK	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	17620-ZM3-816		1	-----	U2T,UMT
5	17672-Z0H-003	FILTER, FUEL	1		
6	17701-Z0Z-000	TUBE, FUEL TANK	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
7	17702-Z0Z-J31	TUBE, FUEL RETURN	1	-----	U2BT,U2ST,U2T,U2TT,UMST,UMT,UMTT
	17702-Z0Z-000		1	-----	UEDT
8	91401-ZM3-003	CLIP, TUBE	2	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
			4	-----	U2NT,UENT,UERT
9	17555-Z0Z-000	GUARD, TANK	1	-----	U2BT,U2NT,UEDT,UENT,UERT
10	90010-Z0H-003	BOLT, SOCKET, 5X30	2	-----	U2BT,UEDT
	90010-Z3E-901		2	-----	U2NT,UENT,UERT
11	90018-Z0H-003	BOLT, SOCKET, 5X16	2	-----	U2BT,UEDT
	90018-Z3E-901		2	-----	U2NT,UENT,UERT
12	91501-Z0H-000	COLLAR, TANK GUARD	2	-----	U2BT,U2NT,UEDT,UENT,UERT
13	91506-ZM3-000	COLLAR A, HEAD COVER	2	-----	U2BT,U2NT,UEDT,UENT,UERT
14	17519-ZM5-003	FITTING	2	-----	U2NT
			1	-----	UENT,UERT
15	17701-Z0Z-800	TUBE COMP., FUEL FEED	1	-----	U2NT,UENT,UERT
16	17702-Z0Z-J40	TUBE, FUEL RETURN	1	-----	U2NT
17	17703-Z6K-801	TUBE A, FUEL	1	-----	U2NT,UENT,UERT
18	17702-Z0H-003	TUBE, FUEL RETURN	1	-----	UENT,UERT

FR.



VK98-E1900

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	6141A5	COIL, IGNITION(ONE)INCLUDES: Engine removal and installation	0.3
3	2161B5	FLYWHEELINCLUDES: Engine removal and installation	0.6
4	6111B3	CORD, STOP SWITCHINCLUDES: Engine removal and installation	0.1


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	30500-Z3F-013	COIL ASSY., IGNITION	1	-----	U2BT,U2NT,UEDT,UENT,UERT
	30500-Z3F-003		1	-----	U2ST,U2TT,UMST,UMTT
	30500-Z0Z-013		1	-----	U2T,UMT
2	30522-Z3F-000	CLIP, HIGH TENSION CORD	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	30522-Z0Z-000		1	-----	U2T,UMT
3	31110-Z3F-003	FLYWHEEL COMP.	1	-----	U2BT,U2NT,U2ST,U2TT,UEDT,UENT,UERT,UMST,UMTT
	31110-Z0Z-003		1	-----	U2T,UMT
4	32195-Z0Z-J00	CORD, STOP SWITCH	1	-----	
5	90012-Z3E-003	BOLT, SOCKET, 4X14	2	-----	U2BT,U2NT,UEDT,UENT,UERT
	90012-Z0H-005		2	-----	U2T,UMT
	90012-Z3E-003		2	1088910	U2ST,U2TT,UMST,UMTT
			2	1088911	U2ST,U2TT,UMST,UMTT
6	94050-08000	NUT, FLANGE, 8MM	1		

E-27

TOP COVER

D15

FR.




VK98-E2700

Ref. No.	L.O.N.	(Relative ref. Number)	Description	F.R.T.
----------	--------	------------------------	-------------	--------

1	1111D6	COVER, ENGINE TOP		0.1
---	--------	-------------------	-------	-----

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	19720-Z0Z-000ZA	COVER COMP., TOP			
		R280.....POWER RED	1		
2	90015-Z0H-003	BOLT, TOP COVER	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	90015-Z3E-900		1	-----	U2NT,UENT,UERT



Ref. L.O.N. (Relative ref. Number) F.R.T.
No. Description


NO INFORMATION

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	87135-ZE2-020	LABEL, E-SPEC(15.5X27.5)	1	----- 1240539	U2T,UMT
2	87521-Z3F-010	MARK, EMBLEM	1	-----	U2BT,U2NT,UEDT,UENT,UERT
	87521-Z0Z-000		1	-----	U2T,UMT
	87521-Z3F-000		1	----- 1247375	U2ST,U2TT,UMST,UMTT
	87521-Z3F-010		1	1247376	----- U2ST,U2TT,UMST,UMTT
3	87531-Z0Z-000	MARK, HONDA	1	-----	
4	87601-Z0H-J40	MARK, TYPE(GY3)	1	-----	U2BT
	87601-Z3F-K60	MARK, TYPE(GD7)	1	-----	U2NT
	87601-Z3F-J80	MARK, TYPE(GY7)	1	-----	U2ST,U2TT,UMST,UMTT
	87601-Z0Z-J60	MARK, TYPE(GY5)	1	-----	U2T,UMT
	87601-Z0H-J30	MARK, TYPE(GY2)	1	-----	UEDT,UERT
	87601-Z3F-K50	MARK, TYPE(GY9)	1	-----	UENT
5	87660-Z0Z-J00	MARK(4-STROKE)	1	-----	

F-1

HANDLE PIPE/THROTTLE LEVER(1)

E 1



VK98-F0100

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	8111F5	TUBE, CORRUGATE	0.1
2	8101N3	LEVER ASSEMBLY, THROTTLE	0.4
3	8111C8	CABLE, THROTTLE	0.4
4	6151D9	SWITCH, ENGINE STOP	0.4
5	8101AG	PIPE ASSEMBLY, HANDLE	0.3
7		(6,8)	
	8101N6	HOLDER, HANDLE	0.1
9	4131E1	GRIP, HANDLE :RIGHT	0.5
10	4131E0	GRIP, HANDLE :LEFT	0.1


3

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	17735-VK9-A00	TUBE, CORRUGATE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
2	17850-VK9-A01	LEVER ASSY., THROTTLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
3	17910-VK9-A00	CABLE COMP., THROTTLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
4	35120-VK9-A01	SWITCH ASSY., ENGINE STOP ...	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
5	53100-VK9-A00	PIPE ASSY., HANDLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
6	53136-VK9-A01	HOLDER A, HANDLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
7	53137-VK9-A01	HOLDER B, HANDLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
8	53138-VK9-A01	HOLDER C, HANDLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
9	53165-VK9-A00	GRIP, R. HANDLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
10	53166-VK9-A00	GRIP, L. HANDLE	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
11	90104-VK9-A01	BOLT, SOCKET, 6X30	6	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
12	90651-MA6-720	BAND, WIRE HARNESS	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
13	93893-05010-00	SCREW-WASHER, 5X10	1	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
14	94002-06000-0S	NUT, HEX., 6MM	2	-----	U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT

F-1-1

HANDLE PIPE/THROTTLE LEVER(2)

E 2



VK98F0101A

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	8101N3	LEVER ASSEMBLY, THROTTLE	0.4
2	8101H1	LEVER, THROTTLE	0.3
4	8101P5	GRIP, THROTTLE LEVER :RIGHT ..	0.3
6	8101P4	GRIP, THROTTLE LEVER :LEFT ...	0.3
8	6111G4	HARNES, THROTTLE WIRE	0.4
10	8101J5	PIPE, HANDLE	0.3
12		(11,13)	
	8101W0	HOLDER B, HANDLE	0.1
14	4131E0	GRIP, HANDLE :LEFT	0.1


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	17850-VK9-L01	LEVER ASSY., THROTTLE	1	-----	U2BT,UEDT,UENT,UERT
2	17851-VH8-761	LEVER, THROTTLE(YELLOW)	1	-----	U2BT,UEDT,UENT,UERT
3	17852-VJ8-C01	LEVER, THROTTLE LOCK	1	-----	U2BT,UEDT,UENT,UERT
4	17853-VF9-V31	GRIP, R. THROTTLE LEVER	1	-----	U2BT,UEDT,UENT,UERT
5	17854-VF9-V31	CAP, THROTTLE LEVER	1	-----	U2BT,UEDT,UENT,UERT
6	17856-VF9-V31	GRIP, L. THROTTLE LEVER	1	-----	U2BT,UEDT,UENT,UERT
7	17859-VF9-V31	SPRING, THROTTLE LEVER	1	-----	U2BT,UEDT,UENT,UERT
8	32100-VK9-L01	HARNES ASSY., WIRE	1	-----	U2BT,UEDT,UENT,UERT
10	53100-VK9-L00	PIPE ASSY., HANDLE	1	-----	U2BT,UEDT,UENT,UERT
11	53136-VK9-A01	HOLDER A, HANDLE	1	-----	U2BT,UEDT,UENT,UERT
12	53137-VK9-A01	HOLDER B, HANDLE	1	-----	U2BT,UEDT,UENT,UERT
13	53138-VK9-A01	HOLDER C, HANDLE	1	-----	U2BT,UEDT,UENT,UERT
14	53166-VK9-A00	GRIP, L. HANDLE	1	-----	U2BT,UEDT,UENT,UERT
15	90101-VF9-V31	SCREW, TAPPING, 4X20	2	-----	U2BT,UEDT,UENT,UERT
16	90104-VK9-A01	BOLT, SOCKET, 6X30	6	-----	U2BT,UEDT,UENT,UERT
17	90651-MA6-720	BAND, WIRE HARNES	1	-----	U2BT,UEDT,UENT,UERT
18	93500-05030-0G	SCREW, PAN, 5X30	1	-----	U2BT,UEDT,UENT,UERT
19	93893-05010-00	SCREW-WASHER, 5X10	1	-----	U2BT,UEDT,UENT,UERT
20	94002-05070-0S	NUT, HEX., 5MM	1	-----	U2BT,UEDT,UENT,UERT
21	94002-06000-0S	NUT, HEX., 6MM	2	-----	U2BT,UEDT,UENT,UERT

3

F-2

GEAR CASE(1)

E 3



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	2091J8	SHAFT, CUTTER BLADE GEAR	0.8
2	2161B0	CASE ASSEMBLY, CUTTER BLADE GEAR	0.2
3	2161B1	CASE, CUTTER BLADE GEAR	0.6
4	2091K2	PINION, CUTTER BLADE GEAR	0.4
5	2091J9	GEAR, CUTTER BLADE BEVEL	0.7
7	4151B8	DEFLECTOR, GRASS	0.1
15	2091K1	BEARING, CUTTER BLADE GEAR SHAFT :UPPER	0.7
	2091K3	BEARING, CUTTER BLADE GEAR PINION :INNER	0.4
16	2091K4	BEARING, CUTTER BLADE GEAR PINION :OUTER	0.4
17	2091K0	BEARING, CUTTER BLADE GEAR SHAFT :LOWER	0.7


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	23326-VK9-A02	SHAFT, GEAR	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
2	41100-VK9-A02	CASE COMP., GEAR	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
3	41101-VK9-A01	CASE, GEAR	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
4	41131-VK9-A01	PINION, BEVEL	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
5	41141-VK9-A01	GEAR, BEVEL	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
6	76200-VK9-A01	DEFLECTOR ASSY., GRASS	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
7	76245-VK9-A01	DEFLECTOR COMP., GRASS	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
8	76248-VK9-A01	HOLDER, PROTECTOR	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
9	90104-VK9-A01	BOLT, SOCKET, 6X30	3	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
10	90115-VK9-A01	BOLT, SOCKET, 10X12	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
11	90105-VK9-A01	SCREW, TAPPING, 5X10	1	-----	U2BT,U2NT
	93893-05010-00	SCREW-WASHER, 5X10	1	-----	1003018 U2ST,U2T,U2TT,UMST,UMT,UMTT
	90105-VK9-A01	SCREW, TAPPING, 5X10	1	1003019	U2ST,U2T,U2TT,UMST,UMT,UMTT
12	94510-12000	CIRCLIP, EXTERNAL, 12MM	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
13	94520-28000	CIRCLIP, INTERNAL, 28MM	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
14	94520-35000	CIRCLIP, INTERNAL, 35MM	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
15	96100-60010-00	BEARING, RADIAL BALL, 6001 ..	2	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
16	96120-60010-00	BEARING, RADIAL BALL, 6001 ..	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT
17	96150-62020-10	BEARING, RADIAL BALL, 6202UU	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT

3

F-2-1

GEAR CASE(2)


E 4



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	2091J8	SHAFT, CUTTER BLADE GEAR	0.8
2	2161B0	CASE ASSEMBLY, CUTTER BLADE GEAR	0.2
3	2091K2	PINION, CUTTER BLADE GEAR	0.4
4	2091J9	GEAR, CUTTER BLADE BEVEL	0.7
6	4151B8	DEFLECTOR, GRASS	0.1
19	2091K3	BEARING, CUTTER BLADE GEAR PINION :INNER	0.4
20	2091K1	BEARING, CUTTER BLADE GEAR SHAFT :UPPER	0.7
21	2091K4	BEARING, CUTTER BLADE GEAR PINION :OUTER	0.4
22	2091K0	BEARING, CUTTER BLADE GEAR SHAFT :LOWER	0.7
23	2161B1	CASE, CUTTER BLADE GEAR	0.6

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	23326-VK9-A02	SHAFT, GEAR	1	-----	UEDT,UENT,UERT
2	41100-VK9-L01	CASE COMP., GEAR	1	-----	UEDT,UENT,UERT
3	41131-VK9-A01	PINION, BEVEL	1	-----	UEDT,UENT,UERT
4	41141-VK9-A01	GEAR, BEVEL	1	-----	UEDT,UENT,UERT
5	72571-VK9-L01	PLATE, NYLON CUTTING	1	-----	UEDT,UENT,UERT
6	76200-VK9-L01	DEFLECTOR ASSY., GRASS	1	-----	UEDT,UENT,UERT
7	76248-VK9-L01	HOLDER, PROTECTOR	1	-----	UEDT,UENT,UERT
8	90101-VK9-L01	BOLT, SOCKET, 5X20	4	-----	UEDT,UENT,UERT
9	90102-VK9-L01	SCREW-WASHER, 5X14	1	-----	UEDT,UENT,UERT
10	90103-VK9-L01	BOLT, SOCKET, 6X25	2	-----	UEDT,UENT,UERT
12	90301-VK9-L01	NUT, LOCK, 6MM	2	-----	UEDT,UENT,UERT
13	92201-06008-OA	BOLT, HEX., 6X8	1	-----	UEDT,UENT,UERT
14	92201-06020-OA	BOLT, HEX., 6X20	2	-----	UEDT,UENT,UERT
	90104-VK9-L01		2	-----	UENT,UERT
15	94101-06000	WASHER, PLAIN, 6MM	4	-----	UEDT,UENT,UERT
	90105-VK9-L01		4	-----	UENT,UERT
16	94510-12000	CIRCLIP, EXTERNAL, 12MM	1	-----	UEDT,UENT,UERT
17	94520-28000	CIRCLIP, INTERNAL, 28MM	1	-----	UEDT,UENT,UERT
18	94520-35000	CIRCLIP, INTERNAL, 35MM	1	-----	UEDT,UENT,UERT
19	96100-60010-00	BEARING, RADIAL BALL, 6001 ..	1	-----	UEDT,UENT,UERT
20	96100-60013-00	BEARING, RADIAL BALL, 6001 ..	1	-----	UEDT,UENT,UERT
21	96120-60010-00	BEARING, RADIAL BALL, 6001 ..	1	-----	UEDT,UENT,UERT
22	96150-62020-10	BEARING, RADIAL BALL, 6202UU	1	-----	UEDT,UENT,UERT
23	41101-VK9-L01	CASE, GEAR	1	-----	UEDT,UENT,UERT

3





VK98-F0300A

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	2121C0	OUTER, CLUTCHINCLUDES: Engine removal and installation	0.4
2	2121E8	HOUSING ASSEMBLY, CLUTCHINCLUDES: Engine removal and installation	0.3
3	2121B6	HOUSING, CLUTCHINCLUDES: Engine removal and installation	0.7
4	4101M4	PIPE, FRAMEINCLUDES: Engine removal and installation	0.5
5	2131J5	SHAFT, DRIVEINCLUDES: Engine removal and installation	0.2
6	4101C3	BRACKET, ENGINE MOUNTINGINCLUDES: Engine removal and installation	0.6
7	4101Q9	RUBBER, ENGINE MOUNTINGINCLUDES: Engine removal and installation	0.6
20	2121E7	BEARING, CLUTCH OUTERINCLUDES: Engine removal and installation	0.5

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	22100-VK9-A02	OUTER COMP., CLUTCH	1		
2	22260-VK9-A02	HOUSING ASSY., CLUTCH	1		
3	22261-VK9-A01	HOUSING, CLUTCH(A)	1		
4	40230-VK9-A00	PIPE ASSY., FRAME	1	----- U2BT,U2NT,U2ST,U2T,U2TT,UMST,UMT,UMTT	
	40230-VK9-L00		1	----- UEDT,UENT,UERT	
5	41411-VK9-A00	SHAFT, DRIVE	1		
6	50225-VK9-A01	BRACKET, ENGINE MOUNTING	1		
7	50237-VK9-A01	RUBBER, ENGINE MOUNTING	1		
8	50374-VK9-A00	HANGER(A)	1		
9	50376-VK9-A00	HANGER(B)	1		
10	50378-VK9-A00	HANGER(C)	1		
11	51511-VK9-A00	STAND	1	----- U2ST,U2T,U2TT,UMST,UMT,UMTT	
12	90011-VK9-A01	BOLT, TAPPING, 5X12	2	----- U2ST,U2T,U2TT,UMST,UMT,UMTT	
13	90102-VK9-A01	BOLT, SOCKET, 6X20	4		
14	90104-VK9-A01	BOLT, SOCKET, 6X30	1		
15	90105-VK9-A01	SCREW, TAPPING, 5X10	1	----- U2BT,U2NT,UEDT,UENT,UERT	
	93893-05010-00	SCREW-WASHER, 5X10	1	----- 1003018 U2ST,U2T,U2TT,UMST,UMT,UMTT	
	90105-VK9-A01	SCREW, TAPPING, 5X10	1	1003019 ----- U2ST,U2T,U2TT,UMST,UMT,UMTT	
16	93893-05020-07	SCREW-WASHER, 5X20	1		
17	94510-15000	CIRCLIP, EXTERNAL, 15MM	1		
18	94520-35000	CIRCLIP, INTERNAL, 35MM	1		
19	94520-45000	CIRCLIP, INTERNAL, 45MM	1		
20	96130-62020-10	BEARING, RADIAL BALL, 6202 ..	1		

E 6


3



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
2	2161B9	HOLDER, BLADE (A)	0.1
4		(9)	
4	2161A4	BLADE, CUTTER	0.1
6	2161N1	BLADE SET, CUTTER	0.1

VK98F0401A

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	21911-VK9-A01	GUARD, GRASS	1	-----	U2BT,U2NT,U2ST,U2T,U2TT
	21911-VK9-L01		1	-----	UEDT,UENT,UERT
2	41125-VK9-A01	HOLDER A, BLADE	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT
3	41126-VK9-A01	HOLDER B, BLADE	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT
4	72511-VK9-A01	BLADE(2-TEETH)	1	-----	U2BT,U2NT,U2ST,U2T,U2TT
5	72623-VK9-A01	COVER, BOLT	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT
6	72800-VK9-A01	BLADE SET(2BLADE)	1	-----	U2BT,U2NT,U2ST,U2T,U2TT
7	90301-VK9-A01	NUT, FLANGE, 10MM	1	-----	U2BT,U2NT,U2ST,U2T,U2TT,UEDT,UENT,UERT
8	90105-VK9-A01	SCREW, TAPPING, 5X10	3	-----	U2BT,U2NT,UEDT,UENT,UERT
	93893-05010-00	SCREW-WASHER, 5X10	3	-----	1003018 U2ST,U2T,U2TT
	90105-VK9-A01	SCREW, TAPPING, 5X10	3	1003019	U2ST,U2T,U2TT
9	72511-VK9-L01	BLADE, CUTTER(3-TEETH)	1	-----	UEDT,UENT,UERT



VK98F2800B

Ref. No.	L.O.N. (Relative ref. Number)	Description	F.R.T.
----------	-------------------------------	-------------	--------


NO INFORMATION

Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	87150-VF9-A00	MARK, CAUTION	1		
2	87521-VK9-A00	MARK, EMBLEM	1		
3	87594-VF9-L00	MARK, OIL CAUTION	1	----- U2BT,UEDT,UENT	
4	87594-VF9-G11	MARK, OIL CAUTION	1	----- UERT	

F-29

TOOL

E 9



VK98-F2900A

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
----------	--------	---------------------------------------	--------

NO INFORMATION


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	89101-VK9-A01	BAG, TOOL	1		
2	89216-VK9-A01	WRENCH, BOX (P16X17)	1		
3	89221-KW3-000	WRENCH, HEX., 4MM	1		
4	89221-MJ4-000	WRENCH, HEX., 5MM	1		
5	89226-KW7-900	SPANNER, 8X10	1	-----	U2BT,U2ST,U2T,U2TT,UEDT,UMST,UMT,UMTT
	89211-KWW-601	SPANNER, 8X10(ATC)	1	-----	U2NT,UENT,UERT

3

F-40

SHOULDER BELT

E10



Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
----------	--------	---------------------------------------	--------

NO INFORMATION


Ref. No.	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
			UMK 435 T		
1	60156-VK9-A01	SCREEN, DUST	1		
2	68150-VK9-A01	BELT ASSY., SHOULDER	1		
3	89104-VK9-A00	CARRY BAG	1		

3

F-40-1

NYLON CUTTER

E11



VK98F4001

Ref. No.	L.O.N.	(Relative ref. Number) Description	F.R.T.
1	2161G7	CUTTER, NYLON	0.1
3	2161J3	(4) SPOOL, NYLON CUTTER	0.2

3

Ref. No.	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
1	72560-VL5-G41	CUTTER ASSY., NYLON	1	-----	UEDT,UENT,UERT
2	72562-VL5-G41	EYELET	2	-----	UEDT,UENT,UERT
3	72563-VL5-G41	SPOOL	1	-----	UEDT,UENT,UERT
4	72564-VL5-G41	SPRING	1	-----	UEDT,UENT,UERT
5	72566-VL5-G41	COVER	1	-----	UEDT,UENT,UERT

PART NO. INDEX

F 1

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
10000				16000				17850-VK9-A01	E1	34	2	28459-Z0H-003	D6	23	7	51000			
10100-Z0Z-405	D1	18	1	16010-ZM3-004	D8	25	1	17850-VK9-L01	E2	35	1	28461-Z3F-M01	D6	23	8	51511-VK9-A00	E5	38	11
10100-Z3F-405	D1	18	1	16011-Z0H-013	D8	25	2	17851-VH8-761	E2	35	2	28461-ZM3-003	D6	23	8				
10100-Z3F-406	D2	19	30	16013-Z0H-003	D8	25	3	17852-VJ8-C01	E2	35	3	28462-ZM3-003	D6	23	9	53000			
12000				16014-ZM3-004	D8	25	4	17853-VF9-V31	E2	35	4								
12209-Z0H-003	D4	21	1	16015-Z0H-013	D8	25	5	17854-VF9-V31	E2	35	5	30000				53100-VK9-A00	E1	34	5
12209-Z3E-000	D4	21	1	16015-Z3F-J42	D8	25	5	17856-VF9-V31	E2	35	6	30500-Z0Z-013	D14	31	1	53100-VK9-L00	E2	35	10
12209-Z3E-003	D4	21	1	16017-ZM3-004	D8	25	6	17859-VF9-V31	E2	35	7	30500-Z3F-003	D14	31	1	53136-VK9-A01	E1	34	6
12310-Z0Z-000	D1	18	2	16018-ZM3-802	D8	25	7	17910-VK9-A00	E1	34	3	30500-Z3F-013	D14	31	1				
12312-Z0Z-300	D1	18	3	16019-ZM3-004	D8	25	8	18000				30522-Z0Z-000	D14	31	2	53137-VK9-A01	E1	34	7
12314-Z0H-300	D1	18	4	16020-ZM3-004	D8	25	9	18310-Z0Z-010	D12	29	1	30522-Z3F-000	D14	31	2				
12367-Z0H-000	D1	18	5	16021-Z3F-J42	D8	25	10	18310-Z0Z-020	D12	29	1					53138-VK9-A01	E1	34	8
				16021-ZM3-004	D8	25	10	18515-Z0Z-300	D12	29	2	31000							
				16022-ZM3-014	D8	25	11	18518-Z0Z-020	D12	29	3	31110-Z0Z-003	D14	31	3	53165-VK9-A00	E1	34	9
				16023-ZM3-004	D8	25	12					31110-Z3F-003	D14	31	3	53166-VK9-A00	E2	35	14
				16024-Z0H-003	D8	25	13	19000				31914-Z0H-003	D1	18	17				
				16025-ZM3-004	D8	25	14	19611-Z0Z-000	D7	24	1	31915-Z0H-003	D1	18	17	60000			
13010-ZM5-000	D3	20	1	16026-ZM3-004	D8	25	15	19631-Z0Z-010	D9	26	25	31916-Z0H-003	D1	18	17	60156-VK9-A01	E10	43	1
13101-Z0Z-000	D3	20	2	16027-ZM3-004	D8	25	16	19720-Z0Z-000ZA	D15	32	1	32000				68000			
13101-Z0Z-010	D3	20	2	16028-ZM3-004	D8	25	17	21000				32100-VK9-L01	E2	35	8				
13111-ZM5-000	D3	20	3	16029-ZM3-004	D8	25	18	21911-VK9-A01	E6	39	1	32195-Z0Z-J00	D14	31	4	68150-VK9-A01	E10	43	2
13310-Z0Z-000	D3	20	4	16030-ZM3-004	D8	25	19												
13310-Z0Z-010	D3	20	4	16031-ZM3-004	D8	25	20	21911-VK9-L01	E7	40	1	35000				72000			
13310-Z0Z-305	D3	20	7	16032-ZM3-004	D8	25	21	21914-VK9-A31	E6	39	2	35120-VK9-A01	E1	34	4	72511-VK9-A01	E7	40	4
13310-Z3F-305	D3	20	7	16035-ZM3-802	D8	25	22					40000				72511-VK9-A31	E6	39	5
				16100-Z0Z-814	D9	26	23	22000				40230-VK9-A00	E5	38	4	72511-VK9-L01	E7	40	9
				16100-Z0Z-815	D9	26	23	22000-Z0Z-003	D7	24	2	40230-VK9-L00	E5	38	4	72512-VK9-A31	E6	39	6
				16100-Z3F-J42	D8	25	23	22000-Z3F-004	D7	24	2					72560-VL5-G41	E11	44	1
				16100-Z3F-K52	D9	26	23	22100-VK9-A02	E5	38	1	41000				72562-VL5-G41	E11	44	2
				16221-Z0Z-000	D9	26	24	22253-Z0Z-003	D7	24	3					72563-VL5-G41	E11	44	3
				17000				22253-Z3F-000	D7	24	3	41100-VK9-A02	E3	36	2	72564-VL5-G41	E11	44	4
				17204-Z3F-000	D11	28	1	22254-Z0Z-003	D7	24	3	41100-VK9-L01	E4	37	2	72566-VL5-G41	E11	44	5
				17211-Z0Z-000	D10	27	1	22254-Z0Z-003	D7	24	3	41101-VK9-A01	E3	36	3	72571-VK9-L01	E4	37	5
				17211-Z3F-000	D11	28	2	22254-Z3F-000	D7	24	4	41101-VK9-A01	E3	36	3	72615-VK9-A31	E6	39	7
				17220-Z0Z-000	D10	27	2	22254-ZM5-003	D7	24	4	41101-VK9-L01	E4	37	23	72623-VK9-A01	E7	40	5
				17220-Z0Z-010	D10	27	2	22255-Z3F-000	D7	24	5	41125-VK9-A01	E6	39	3	72624-VK9-A31	E6	39	8
				17220-Z3F-000	D11	28	3	22260-VK9-A02	E5	38	2	41126-VK9-A01	E7	40	2	72800-VK9-A01	E7	40	6
				17231-Z0Z-000	D10	27	3	22261-VK9-A01	E5	38	3					72800-VK9-A31	E6	39	9
				17231-Z0Z-010	D10	27	3					41131-VK9-A01	E3	36	4				
				17231-Z3F-000	D11	28	4	23000				41141-VK9-A01	E3	36	5	76000			
				17504-ZM3-003	D13	30	1	23326-VK9-A02	E3	36	1					76200-VK9-A01	E3	36	6
				17511-Z0Z-013	D13	30	2					41141-VK9-A01	E3	36	5	76200-VK9-L01	E4	37	6
				17519-ZM5-003	D13	30	14									76245-VK9-A01	E3	36	7
				17533-Z0H-000	D13	30	3	28000				41411-VK9-A00	E5	38	5	76248-VK9-A01	E3	36	8
				17555-Z0Z-000	D13	30	9	28400-Z0Z-003	D6	23	1	50000				76248-VK9-L01	E4	37	7
				17620-ZM3-816	D13	30	4	28400-Z3F-M01	D6	23	1								
				17620-ZM3-817	D13	30	4	28414-Z0Z-000	D6	23	2	50225-VK9-A01	E5	38	6	87000			
				17672-Z0H-003	D13	30	5	28414-Z3F-M01	D6	23	2	50237-VK9-A01	E5	38	7	87135-ZE2-020	D16	33	1
				17701-Z0Z-000	D13	30	6	28421-ZM3-003	D6	23	3	50374-VK9-A00	E5	38	8	87150-VF9-A00	E8	41	1
				17701-Z0Z-800	D13	30	15	28433-ZM3-003	D6	23	4	50376-VK9-A00	E5	38	9	87521-VK9-A00	E8	41	2
				17702-Z0H-003	D13	30	18	28442-Z0H-003	D6	23	5	50378-VK9-A00	E5	38	10	87521-Z0Z-000	D16	33	2
				17702-Z0Z-000	D13	30	7	28451-Z0H-003	D6	23	6					87521-Z3F-000	D16	33	2
				17702-Z0Z-J31	D13	30	7												
				17702-Z0Z-J40	D13	30	16												
				17703-Z6K-801	D13	30	17												
				17735-VK9-A00	E1	34	1												
15000																			
15422-Z0Z-000	D1	18	10																
15510-Z0H-000	D1	18	11																
15510-Z3E-000	D2	19	29																
15571-ZM3-003	D1	18	12																
15600-Z3F-000	D1	18	14																
15600-ZM3-003	D1	18	14																
15625-Z0T-800	D1	18	15																
15625-ZE1-003	D1	18	15																
15721-Z0Z-000	D1	18	16																

4

PART NO. INDEX

F 2

Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.	Part Number	Address	Page	Ref.
87521-Z3F-010	D16	33	2		D11	28	6	92201-06020-0A	E4	37	14								
87531-Z0Z-000	D16	33	3		D12	29	5												
87594-VF9-G11	E8	41	4		D13	30	11	93000											
87594-VF9-L00	E8	41	3	90019-Z0H-003	D2	19	23												
87601-Z0H-J30	D16	33	4	90101-VF9-V31	E2	35	15	93500-03005-0A	D2	19	25								
87601-Z0H-J40	D16	33	4	90101-VK9-L01	E4	37	8	93500-05030-0G	E2	35	18								
87601-Z0Z-J60	D16	33	4	90102-VK9-A01	E5	38	13	93893-05010-00	E1	34	13								
87601-Z3F-J80	D16	33	4	90102-VK9-L01	E4	37	9		E2	35	19								
87601-Z3F-K50	D16	33	4	90102-Z0Z-003	D11	28	7		E3	36	11								
87601-Z3F-K60	D16	33	4	90103-VK9-L01	E4	37	10		E5	38	15								
87660-Z0Z-J00	D16	33	5	90104-VK9-A01	E1	34	11		E6	39	15								
					E2	35	16		E7	40	8								
89000					E3	36	9	93893-05020-07	E5	38	16								
					E5	38	14												
89101-VK9-A01	E9	42	1	90104-VK9-L01	E4	37	14	94000											
89104-VK9-A00	E10	43	3	90105-VK9-A01	E3	36	11												
89211-KWW-601	E9	42	5		E5	38	15	94002-05070-0S	E2	35	20								
89216-VK9-A01	E9	42	2		E6	39	15	94002-06000-0S	E1	34	14								
89221-KW3-000	E9	42	3		E7	40	8		E2	35	21								
89221-MJ4-000	E9	42	4	90105-VK9-L01	E4	37	15	94050-05000	D10	27	6								
89226-KW7-900	E9	42	5	90114-VK9-A31	E6	39	11		D11	28	11								
				90115-VK9-A01	E3	36	10	94050-08000	D14	31	6								
90000				90136-SM4-901	D12	29	6	94101-06000	E4	37	15								
				90206-ZM3-000	D2	19	24	94305-40102	D2	19	26								
90001-Z0Z-003	D12	29	4	90301-VK9-A01	E7	40	7	94510-12000	E3	36	12								
90001-Z0Z-013	D12	29	4	90301-VK9-A31	E6	39	12		E4	37	16								
90009-Z0H-003	D1	18	18	90301-VK9-L01	E4	37	12	94510-15000	E5	38	17								
	D7	24	6	90401-VK9-A31	E6	39	13		E6	39	16								
90009-Z0Z-003	D10	27	4	90501-VK9-A31	E6	39	14	94520-28000	E3	36	13								
90009-Z3E-901	D1	18	18	90651-MA6-720	E1	34	12		E4	37	17								
	D7	24	6		E2	35	17	94520-35000	E3	36	14								
90009-Z3F-901	D10	27	4						E4	37	18								
	D11	28	5	91000					E5	38	18								
90010-Z0H-003	D13	30	10					94520-45000	E5	38	19								
90010-Z0Z-003	D1	18	19	91212-Z0H-003	D3	20	5												
90010-Z3E-901	D13	30	10	91212-Z3E-000	D3	20	5	95000											
90011-VK9-A01	E5	38	12	91212-Z3E-003	D3	20	5												
90012-Z0H-005	D14	31	5	91214-Z3F-000	D3	20	6	95002-41200-08	D2	19	27								
90012-Z3E-003	D14	31	5	91214-Z3F-003	D3	20	6	95002-41300-04	D2	19	28								
90012-ZM3-003	D6	23	10	91214-ZM3-003	D3	20	6												
90013-VK9-A31	E6	39	10	91301-ZM3-000	D9	26	28	96000											
90013-Z0H-004	D2	19	20	91308-Z0H-003	D9	26	29												
90013-Z0Z-003	D2	19	21	91308-Z3E-000	D9	26	29	96100-60010-00	E3	36	15								
90013-Z3E-003	D1	18	20	91401-ZM3-003	D13	30	8		E4	37	19								
	D2	19	20	91501-Z0H-000	D13	30	12	96100-60013-00	E4	37	20								
90013-Z3F-003	D2	19	21	91501-Z0Z-000	D10	27	7	96120-60010-00	E3	36	16								
90014-Z0H-003	D9	26	26	91501-Z3F-000	D11	28	8		E4	37	21								
90014-Z3F-000	D9	26	26	91502-Z3F-000	D11	28	9	96130-62020-10	E5	38	20								
90015-Z0H-003	D15	32	2	91503-Z3F-000	D11	28	10		E6	39	17								
90015-Z3E-900	D15	32	2	91503-ZM3-000	D10	27	8	96150-62020-10	E3	36	17								
90017-Z0H-000	D2	19	22	91504-ZM3-003	D6	23	12		E4	37	22								
90018-Z0H-003	D6	23	11	91506-ZM3-000	D6	23	13												
	D9	26	27		D10	27	9	99000											
	D10	27	5		D12	29	7												
	D12	29	5		D13	30	13	99101-Z0Z-0360	D9	26	30								
	D13	30	11					99101-Z0Z-0370	D9	26	30								
90018-Z3E-901	D6	23	11	92000				99101-Z0Z-0380	D9	26	30								
	D9	26	27					99101-ZM5-0350	D9	26	30								
	D10	27	5	92201-06008-0A	E4	37	13												

PART NAME INDEX

G 1

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
[A]				BOLT, TOP COVER	D15	32	2	CUTTER ASSY., NYLON.....	E11	44	1
ARM, EX. VALVE ROCKER	D1	18	7	BRACKET, ENGINE MOUNTING	E5	38	6	[D]			
ARM, IN. VALVE ROCKER	D1	18	6	[C]				DEFLECTOR ASSY., GRASS.....	E3	36	6
ARM, SWING	D6	23	7	CABLE COMP., THROTTLE	E1	34	3	DEFLECTOR COMP., GRASS.....	E4	37	6
[B]				CAP ASSY., FUEL TANK	D13	30	4	DEFLECTOR COMP., GRASS.....	E3	36	7
BAG, TOOL	E9	42	1	CAP ASSY., OIL FILLER	D1	18	14	DIAPHRAGM ASSY., METERING.....	D8	25	3
BAND, WIRE HARNESS	E1	34	12	CAP, THROTTLE LEVER	E2	35	5	DIAPHRAGM, PUMP	D8	25	4
BEARING, RADIAL BALL, 6001 ...	E2	35	17	CARBURETOR ASSY.	D8	25	23	[E]			
	E3	36	15	CARRY BAG	D9	26	23	ELEMENT, AIR CLEANER.....	D10	27	1
	E4	37	19	CASE COMP., AIR CLEANER	E10	43	3	EYELET.....	D11	28	2
				CASE COMP., GEAR	D10	27	2	EYELET.....	E11	44	2
				CASE COMP., GEAR	D11	28	3	[F]			
BEARING, RADIAL BALL, 6202 ...	E5	38	20	CASE SET ASSY., CRANK	E3	36	3	FILTER, BREATHER.....	D1	18	5
BEARING, RADIAL BALL, 6202UU -	E6	39	17	CASE, GEAR	E4	37	23	FILTER, FUEL.....	D13	30	5
	E3	36	17	CASE, RECOIL STARTER	E4	37	23	FILTER, FUEL INLET.....	D8	25	22
BELT ASSY., SHOULDER	E4	37	22	CIRCLIP, EXTERNAL, 12MM	E4	37	16	FITTING.....	D13	30	14
BELT, TIMING	E10	43	2	CIRCLIP, EXTERNAL, 15MM	E5	38	17	FLYWHEEL COMP.....	D14	31	3
BLADE	D4	21	4	CIRCLIP, EXTERNAL, 15MM	E6	39	16	[G]			
BLADE SET	E6	39	5	CIRCLIP, INTERNAL, 28MM	E6	39	16	GASKET, METERING DIAPHRAGM....	D8	25	1
BLADE, CUTTER	E7	40	4	CIRCLIP, INTERNAL, 28MM	E3	36	13	GASKET, PUMP.....	D8	25	2
BLADE, CUTTER	E7	40	9	CIRCLIP, INTERNAL, 35MM	E4	37	17	GEAR, BEVEL.....	E3	36	5
BODY ASSY., AIR PURGE	D8	25	6	CIRCLIP, INTERNAL, 35MM	E4	37	18	GRIP, L. HANDLE	E4	37	4
BODY ASSY., PUMP	D8	25	5	CIRCLIP, INTERNAL, 45MM	E5	38	18	GRIP, L. HANDLE	E1	34	10
BOLT-WASHER, 6X16	E6	39	11	CLAMP, TUBE	E5	38	19	GRIP, R. HANDLE	E2	35	14
BOLT, 5X53	D9	26	26	CIRCLIP, INTERNAL, 45MM	D2	19	27	GRIP, R. THROTTLE LEVER	E2	35	6
BOLT, 5X58	D9	26	26	CLAMP, TUBE	D2	19	27	GRIP, R. THROTTLE LEVER	E1	34	9
BOLT, CLUTCH	D7	24	3	CLIP, HIGH TENSION CORD	D14	31	2	GRIP, R. THROTTLE LEVER	E2	35	4
BOLT, HEX., 6X20	E4	37	14	CLIP, TUBE	D13	30	8	GROMMET, FUEL TUBE.....	D13	30	1
BOLT, HEX., 6X8	E4	37	13	CLUTCH ASSY.	D7	24	2	GROMMET, HEAD COVER.....	D1	18	4
BOLT, SOCKET, 10X12	E3	36	10	COIL ASSY., IGNITION	D14	31	1	GUARD, GRASS	E6	39	1
BOLT, SOCKET, 4X14	D14	31	5	COLLAR	D6	23	12	GUARD, GRASS	E7	40	2
BOLT, SOCKET, 5X12	D2	19	23	COLLAR A, HEAD COVER	D6	23	13	GUARD, TANK.....	D13	30	9
BOLT, SOCKET, 5X16	D6	23	11	COLLAR, AIR CLEANER	D10	27	9	GUIDE COMP., UNDER AIR.....	D12	29	3
BOLT, SOCKET, 5X20	D9	26	27	COLLAR, AIR CLEANER CASE	D10	27	7	GUIDE, AIR.....	D12	29	2
	D10	27	5	COLLAR, AIR CLEANER CASE	D11	28	8	GUIDE, ROPE.....	D6	23	4
	D11	28	6	COLLAR, TANK GUARD	D11	28	8	[H]			
	D12	29	5	CORD, STOP SWITCH	D13	30	12	HANGER.....	E5	38	8
	D13	30	11	COVER	D14	31	4	HARNES ASSY., WIRE.....	E2	35	8
BOLT, SOCKET, 5X25	D1	18	18	COVER COMP., TOP	E11	44	5		HOLDER A, BLADE	E6	39
BOLT, SOCKET, 5X30	D7	24	6	COVER COMP., TOP	D15	32	1	HOLDER A, BLADE	E7	40	2
	E4	37	8	COVER, AIR CLEANER	D10	27	3	HOLDER A, HANDLE	E1	34	6
BOLT, SOCKET, 5X32	D10	27	4	COVER, AIR CLEANER	D11	28	4	HOLDER A, HANDLE	E2	35	11
BOLT, SOCKET, 5X32	D11	28	5	COVER, BOLT	D11	28	4	HOLDER B, BLADE	E6	39	4
BOLT, SOCKET, 6X12	D13	30	10	COVER, CYLINDER HEAD	E7	40	5	HOLDER B, BLADE	E7	40	3
BOLT, SOCKET, 6X20	D1	18	19	COVER, FAN	D1	18	2	HOLDER B, HANDLE	E1	34	7
BOLT, SOCKET, 6X20	E6	39	10	COVER, FAN	D7	24	1	HOLDER B, HANDLE	E2	35	12
BOLT, SOCKET, 6X25	E5	38	13	COVER, PRIMER PUMP	D7	24	1				
BOLT, SOCKET, 6X25	E4	37	10	COVER, PRIMER PUMP	D8	25	15				
BOLT, SOCKET, 6X30	E1	34	11	CRANKCASE SET	D1	18	1				
BOLT, STUD, 5X56.5	E2	35	16	CRANKSHAFT COMP.	D1	18	1				
	E3	36	9	CRANKSHAFT COMP.	D3	20	4				
	E5	38	14	CRANKSHAFT COMP.	D3	20	4				
	D12	29	4	CRANKSHAFT COMP.	D3	20	4				
	E5	38	12	CRANKSHAFT COMP.	D3	20	4				
BOLT, TAPPING, 5X12	E5	38	12	CRANKSHAFT COMP.	D3	20	4				

PART NAME INDEX

G 2

Part name	Address	Page	Ref.	Part name	Address	Page	Ref.	Part name	Address	Page	Ref.
HOLDER C, HANDLE	E1	34	8	O-RING, 12.3X2.4	D9	26	29	SCREW, SPECIAL, 6X16	D11	28	7
	E2	35	13	O-RING, 14.8X2.4	D9	26	28	SCREW, TAPPET ADJUSTING	D2	19	22
HOLDER, BEARING	E6	39	8	OUTER COMP., CLUTCH	E5	38	1	SCREW, TAPPING, 4X20	E2	35	15
HOLDER, PROTECTOR	E3	36	8					SCREW, TAPPING, 5X10	E3	36	11
	E4	37	7	[P]					E5	38	15
HOUSING ASSY., CLUTCH	E5	38	2						E6	39	15
HOUSING, CLUTCH	E5	38	3	PACKING, CARBURETOR	D9	26	24		E7	40	8
				PACKING, OIL FILLER CAP	D1	18	15	SCREW, THROTTLE COLLAR	D8	25	17
[J]				PINION, BEVEL	E3	36	4	SEAL, HEAD COVER	D1	18	3
JET	D9	26	30		E4	37	3	SEAL, VALVE STEM	D4	21	1
				PIN, 10MM	E6	39	6	SHAFT, DRIVE	E5	38	5
[K]				PIN, METERING LEVER	D8	25	11	SHAFT, GEAR	E3	36	1
KNOB, RECOIL STARTER	D6	23	8	PIN, PISTON	D3	20	3		E4	37	1
				PIN, SPRING, 4X10	D2	19	26	SHROUD	D9	26	25
[L]				PIPE ASSY., FRAME	E5	38	4	SPANNER, 8X10	E9	42	5
LABEL, E-SPEC	D16	33	1	PIPE ASSY., HANDLE	E1	34	5	SPOOL	E11	44	3
LEVER ASSY., THROTTLE	E1	34	2		E2	35	10	SPRING	E11	44	4
	E2	35	1	PISTON	D3	20	2	SPRING, METERING LEVER	D8	25	9
LEVER, METERING	D8	25	12	PLATE ASSY., OIL OUTLET VALVE	D1	18	11	SPRING, PUMP	D8	25	19
LEVER, THROTTLE	E2	35	2		D2	19	29	SPRING, RECOIL STARTER	D6	23	5
LEVER, THROTTLE LOCK	E2	35	3	PLATE, BLADE HOLDER	E6	39	7	SPRING, THROTTLE LEVER	E2	35	7
LIFTER COMP., EX. VALVE	D1	18	9	PLATE, NYLON CUTTING	E4	37	5	SPRING, VALVE	D4	21	7
LIFTER COMP., IN. VALVE	D1	18	8	PLATE, OIL TRAP	D11	28	1	STAND	E5	38	11
				PLUG, SPARK	D1	18	17	STARTER ASSY., RECOIL	D6	23	1
[M]				PULLEY COMP., CAMSHAFT	D4	21	3	SWITCH ASSY., ENGINE STOP	E1	34	4
MARK	D16	33	5	PULLEY, RECOIL STARTER	D6	23	6	SWIVEL	D8	25	16
MARK, CAUTION	E8	41	1	PUMP, PRIMER	D8	25	21				
MARK, EMBLEM	D16	33	2					[T]			
	E8	41	2					TANK, FUEL	D13	30	2
MARK, HONDA	D16	33	3					TUBE A, FUEL	D13	30	17
MARK, OIL CAUTION	E8	41	3					TUBE COMP., FUEL FEED	D13	30	15
								TUBE, BREATHER	D1	18	16
MARK, TYPE	D16	33	4					TUBE, CORRUGATE	E1	34	1
MOWING SET	E6	39	9					TUBE, FUEL RETURN	D13	30	7
MUFFLER COMP.	D12	29	1								16
											18
[N]								TUBE, FUEL TANK	D13	30	6
NUT, FLANGE, 10MM	E7	40	7					TUBE, OIL	D1	18	10
NUT, FLANGE, 5MM	D10	27	6								
	D11	28	11					[V]			
NUT, FLANGE, 8MM	D14	31	6	SCREEN, DUST	E10	43	1	VALVE, EX.	D4	21	6
NUT, HEX., 5MM	E2	35	20	SCREEN, INLET	D8	25	7	VALVE, INLET NEEDLE	D8	25	8
NUT, HEX., 6MM	E1	34	14	SCREW-WASHER, 5X10	E1	34	13	VALVE, IN.	D4	21	5
	E2	35	21		E2	35	19	VALVE, OIL OUTLET	D1	18	12
NUT, LOCK, 6MM	E4	37	12		E3	36	11				
NUT, SELF-LOCK, 5MM	D12	29	6		E5	38	15				
NUT, TAPPET ADJUSTING	D2	19	24		E6	39	15				
NUT, U, 6MM	E6	39	12		E7	40	8				
								[W]			
[O]				SCREW-WASHER, 5X14	E4	37	9	WASHER	D8	25	20
OIL SEAL, 10X20X5	D3	20	5	SCREW-WASHER, 5X20	E5	38	16	WASHER, CLUTCH	E6	39	13
OIL SEAL, 15X25X6	D3	20	6	SCREW, METERING LEVER PIN	D8	25	10	WASHER, PLAIN, 6MM	E4	37	15
O-RING	D8	25	14	SCREW, PAN, 3X5	D2	19	25	WASHER, SPRING, 6MM	E6	39	14
				SCREW, PAN, 4X8	D1	18	20	WASHER, WAVE	D7	24	5
					D2	19	20	WRENCH, BOX	E9	42	2
								WRENCH, HEX., 4MM	E9	42	3
				SCREW, PAN, 5X30	E2	35	18	WRENCH, HEX., 5MM	E9	42	4
				SCREW, PUMP COVER	D8	25	18				
				SCREW, SETTING	D6	23	10				

1

FOREWORD INDEX

2

ENGINE GROUP

3

FRAME GROUP

4

PART NUMBER INDEX

5

PART NAME INDEX



February 28, 2014



PARTS CATALOGUE NEWS

Honda Motor Co., Ltd.

Customer Service Technology Development Division

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	001

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
E-14	23	L	16100-Z0Z-814	CARBURETOR ASSY. (WYB 14B).....	1	-----	U2T, UMT
					1	----- 1804408	U2ST, U2TT, UMST, UMTT
		T	16100-Z0Z-815	CARBURETOR ASSY. (WYB 14D).....	1	-----	UEDT, UERT
					1	1804409 -----	U2ST, U2TT, UMST, UMTT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE



PARTS CATALOGUE NEWS

Service Technology Department, Power Products Operations
Service Division, Honda Motor Co., Ltd.

PARTS CATALOGUE - CORRECTED


Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	002

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
-----------	----------	------	----------	-------------	---------------------------	------------	----------------------

E-17 FUEL TANK

Ref. No.	LON	(Relative ref. Number) Description	FRT
1		(19, 20, 21)	
	3101J0	GROMMET, FUEL TUBE	0.2
7		(15, 16, 18, 23, 24)	
	3101L8	TUBE, FUEL RETURN	0.2
17		(19, 20, 25)	
	3101F1	TUBE, FUEL TANK	0.2



E-17	6	E	17701-Z0Z-000	*PART NO. DELETION
	7	E	17702-Z0Z-J31	*PART NO. DELETION

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

PARTS CATALOGUE NEWS

BOOKNo. : 18VK9604

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.		Parts catalogue code
					UMK 435 T			
	19	D	17700-Z0Z-305	GROMMET ASSY., FUEL TANK.....	1	-----	-----	UEDT
	20	D	17700-Z0Z-306	GROMMET ASSY., FUEL TANK.....	1	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	21	D	17504-ZM3-003	GROMMET, FUEL TUBE.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UEDT, UMST, UMT, UMTT
	22	D	17519-ZM5-003	FITTING.....	(2)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
					(1)	-----	-----	UEDT
	23	D	17701-Z0Z-800	TUBE COMP., FUEL FEED.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UEDT, UMST, UMT, UMTT
	24	D	17702-Z0Z-J40	TUBE, FUEL RETURN.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	25	D	17703-Z6K-801	TUBE A, FUEL.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UEDT, UMST, UMT, UMTT
	26	D	91401-ZM3-003	CLIP, TUBE.....	(2)	-----	-----	U2BT, U2ST, U2T, U2TT, UEDT, UMST, UMT, UMTT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

May 17, 2015



PARTS CATALOGUE NEWS

Service Technology Department, Power Products Operations
Service Division, Honda Motor Co., Ltd.

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	003

(THAILAND-KD)

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
E-10	4	L	14400-Z3F-003	BELT, TIMING(76ZU7 G-300).....	1	----- 2696535	U2BT, UEDT
					1	1022911 2696535	U2ST, U2TT, UMST, UMTT
		T	14400-Z3F-013	BELT, TIMING(76ZU6 G-310).....	1	2696536 -----	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
					1	----- -----	U2NT, UENT, UERT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO. DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

NOTE A:PART NO.CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO.CORRECTION L:APPLICATION SERIAL NO.CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE


BOOKNo. :18VK9604

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
	13	T	91506-ZM3-000	COLLAR A, HEAD COVER.....	2	-----	U2NT, UEDT, UENT, UERT
	20	E	17700-ZOZ-306	*PARTS NO. DELETION			
	21	T	17504-ZM3-003	GROMMET, FUEL TUBE.....	(1)	-----	UEDT
	22	T	17519-ZM5-003	FITTING.....	(1)	-----	UEDT
	23	T	17701-ZOZ-800	TUBE COMP., FUEL FEED.....	(1)	-----	UEDT
	24	E	17702-ZOZ-J40	*PARTS NO. DELETION			
	25	T	17703-Z6K-801	TUBE A, FUEL.....	(1)	-----	UEDT
	26	T	91401-ZM3-003	CLIP, TUBE.....	(2)	-----	UEDT

E-17-1 FUEL TANK (2)

Ref. No.	(Relative ref. Number) Description	FRT
1	(12, 13)	
3101J0	GROMMET, FUEL TUBE	0.2
2 3101H7	TANK, FUEL	0.2
5 3101M7	CAP, FUEL FILLER	0.1
6 3101A6	FILTER, FUEL	0.2
16	(15)	
3101L8	TUBE, FUEL RETURN	0.2
17 3101F1	TUBE, FUEL TANK	0.2

FR.



E-17-1	1	D	17504-ZM3-003	GROMMET, FUEL TUBE.....	1	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	2	D	17511-ZOZ-013	TANK, FUEL.....	1	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	3	D	17533-ZOH-000	RUBBER, TANK MOUNTING.....	4	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	4	D	17555-ZOZ-000	GUARD, TANK.....	1	-----	U2BT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

PARTS CATALOGUE NEWS

BOOKNo. :18VK9604

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY		Serial No.	Parts catalogue code
					UMK 435 T			
	5	D	17620-ZM3-816	CAP ASSY., FUEL TANK.....	1	-----	-----	U2T, UMT
		D	17620-ZM3-817		1	-----	-----	U2BT, U2ST, U2TT, UMST, UMTT
	6	D	17672-Z0H-003	FILTER, FUEL.....	1	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	7	D	90010-Z0H-003	BOLT, SOCKET, 5X30.....	2	-----	-----	U2BT
	8	D	90018-Z0H-003	BOLT, SOCKET, 5X16.....	2	-----	-----	U2BT
	9	D	91401-ZM3-003	CLIP, TUBE.....	2	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	10	D	91501-Z0H-000	COLLAR, TANK GUARD.....	2	-----	-----	U2BT
	11	D	91506-ZM3-000	COLLAR A, HEAD COVER.....	2	-----	-----	U2BT
	12	D	17700-Z0Z-306	GROMMET ASSY., FUEL TANK.....	1	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	13	D	17504-ZM3-003	GROMMET, FUEL TUBE.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	14	D	17519-ZM5-003	FITTING.....	(2)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	15	D	17701-Z0Z-800	TUBE COMP., FUEL FEED.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	16	D	17702-Z0Z-J40	TUBE, FUEL RETURN.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	17	D	17703-Z6K-801	TUBE A, FUEL.....	(1)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT
	18	D	91401-ZM3-003	CLIP, TUBE.....	(2)	-----	-----	U2BT, U2ST, U2T, U2TT, UMST, UMT, UMTT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

October 09, 2015



PARTS CATALOGUE NEWS

Service Technology Department, Power Products Operations
Service Division, Honda Motor Co., Ltd.

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	004

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
E-7	2	L	13101-Z0Z-000	PISTON.....	1	----- 1999676	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
					1	-----	U2T, UMT
		T	13101-Z0Z-010		1	1999677 3309970	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
					1	----- 3309970	U2NT, UENT, UERT
		D	13101-Z3F-000		1	3309971	U2BT, U2NT, U2ST, U2TT, UEDT, UENT, UERT, UMST, UMTT
	4	L	13310-Z0Z-000	CRANKSHAFT COMP.....	1	----- 1999676	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
					1	-----	U2T, UMT
		T	13310-Z0Z-010		1	1999677 3309970	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
					1	----- 3309970	U2NT, UENT, UERT
		D	13310-Z3F-000		1	3309971	U2BT, U2NT, U2ST, U2TT, UEDT, UENT, UERT, UMST, UMTT
	7	T	13310-Z0Z-305	CRANKSHAFT COMP.....	(1)	----- 3309970	U2BT, U2NT, U2ST, U2TT, UEDT, UENT, UERT, UMST, UMTT
		T	13310-Z3F-305		(1)	3309971	U2BT, U2NT, U2ST, U2TT, UEDT, UENT, UERT, UMST, UMTT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE



PARTS CATALOGUE NEWS

Service Technology Department, Power Products Operations
Service Division, Honda Motor Co., Ltd.

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	005

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
E-15	2	L	17220-Z0Z-000	CASE COMP., AIR CLEANER.....	1	-----	U2T, UMT
					1	----- 3142483	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
		T	17220-Z0Z-010		1	-----	UERT
					1	3142484 -----	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
	3	L	17231-Z0Z-000	COVER, AIR CLEANER.....	1	-----	U2T, UMT
					1	----- 1844919	U2ST, U2TT, UMST, UMTT
		T	17231-Z0Z-010		1	-----	U2BT, UEDT, UERT
					1	1844920 -----	U2ST, U2TT, UMST, UMTT
E-16	1	L	18310-Z0Z-010	MUFFLER COMP.....	1	-----	U2T, UMT
					1	----- 3144425	U2BT, U2ST, U2TT, UEDT, UMST, UMTT
		T	18310-Z0Z-020		1	-----	U2NT, UENT, UERT
					1	3144426 -----	U2BT, U2ST, U2TT, UEDT, UMST, UMTT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE




PARTS CATALOGUE NEWS

Service Technology Department, Power Products Operations
Service Division, Honda Motor Co., Ltd.

PARTS CATALOGUE - CORRECTED

Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	006

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY UMK 435 T	Serial No.	Parts catalogue code
E-19				FLYWHEEL			
	Ref. No. LON	(Relative ref. Number) Description		FRT			
	7 6141G6	KIT, IGNITION COIL AND FLYWHEEL INCLUDES: Engine removal and installation		0.6			
							
VK98E1900A							
E-19	1	E	30500-Z0Z-013	*PARTS NO. DELETION			
	3	E	31110-Z0Z-003	*PARTS NO. DELETION			

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

PARTS CATALOGUE NEWS

BOOKNo. :18VK9604

Block No.	Ref. No.	Note	Part No.	Description	Reqd. QTY	Serial No.	Parts catalogue code
					UMK 435 T		
	7	D	06310-Z0Z-305	IGNITION COIL & FLYWHEEL KIT (TEC)	1	-----	U2T, UMT

NOTE A:PART NO. CHANGE D:NEWLY PROVIDED E:PART NO.DELETION K:REQUIRED NO. CORRECTION L:APPLICATION SERIAL NO. CORRECTION
M:PART DESCRIPTION CORRECTION T:APPLICATION CORRECTION Z:REMARKS CHANGE

October 15, 2016



PARTS CATALOGUE NEWS

Service Technology Department, Power Products Operations
Service Division, Honda Motor Co., Ltd.

Printed in Japan

CODE NO.	18VK9604
PARTS CATALOGUE NEWS	UMK435T
NEWS NO.	007

(THAILAND-KD)

UMK435T-UEBT TYPE sales information


NOTE: This Parts Catalogue News explains only the parts of the different model that are produced to conform to addition of the UMK435T-UEBT type.

As for the parts not listed on this Parts Catalogue News, use the parts of the UMK435T-UEDT type.

•Models, parts catalogue codes and applicable serial numbers

Model	Type		Parts catalogue type	Engine		Applicable engine serial No.	Applicable frame serial No.	Applicable carburetor identification No.
				Model	Type			
UMK435T	UEDT	Base type	UEDT	GX35T	GY2	GCAMT-1000001~	HAAT-1000001~	WYB 14D
	UEBT	Additional type	UEBT		GY3			WYB 31

•Features of each type		Base type	Additional type
Specifications	Model	UMK435T	
	Type	UEDT	UEBT
Tank guard		●	●
Cutter blade	2-Teeth		
	3-Teeth	●	●
	Mowing cutter		
	Nylon cutter	●	●



PARTS CATALOGUE NEWS

BOOKNo. : 18VK9604

Block No.	Ref. No.	Part No.	Description	Reqd. QTY	Base Part No.	Parts catalogue code
				UMK 435 T		
E-2	18	90009-Z3E-901	BOLT, SOCKET, 5X20.....	2	90009-Z0H-003	UEBT
E-7	1	13010-Z3F-003	RING SET, PISTON(TPR).....	1		UEBT
E-10	4	14400-Z3F-801	BELT, TIMING(76ZU5 G-310).....	1	14400-Z3F-013	UEBT
	5	14711-Z3F-000	VALVE, IN. (FI).....	1		UEBT
	6	14721-Z3F-000	VALVE, EX. (FE).....	1		UEBT
	8	14771-Z3F-000	RETAINER, VALVE SPRING.....	2	14771-Z0H-000	UEBT
E-11	1	28400-Z3F-M01	STARTER ASSY., RECOIL.....	1	28400-Z0Z-003	UEBT
	2	28414-Z3F-M01	CASE, RECOIL STARTER.....	1	28414-Z0Z-000	UEBT
	8	28461-Z3F-M01	KNOB, RECOIL STARTER.....	1	28461-ZM3-003	UEBT
	11	90018-Z3E-901	BOLT, SOCKET, 5X16.....	1	90018-Z0H-003	UEBT
E-12	6	90009-Z3E-901	BOLT, SOCKET, 5X20.....	3	90009-Z0H-003	UEBT
E-14	5	16015-Z3F-J42	BODY ASSY., PUMP.....	1	16015-Z0H-013	UEBT
	10	16021-Z3F-J42	SCREW, METERING LEVER PIN.....	1	16021-ZM3-004	UEBT
	23	16100-Z3F-J42	CARBURETOR ASSY. (WYB 31).....	1	16100-Z0Z-815	UEBT
	25	19631-Z0Z-020	SHROUD.....	1	19631-Z0Z-010	UEBT
	27	90018-Z3E-901	BOLT, SOCKET, 5X16.....	2	90018-Z0H-003	UEBT
	30	99101-Z0Z-0370	JET (#37).....	(1)	99101-ZM5-0350	UEBT
		99101-Z0Z-0380	JET (#38).....	1	99101-Z0Z-0370	UEBT
E-15	4	90009-Z3F-901	BOLT, SOCKET, 5X25.....	1	90009-Z0Z-003	UEBT
	5	90018-Z3E-901	BOLT, SOCKET, 5X16.....	1	90018-Z0H-003	UEBT
E-16	5	90018-Z3E-901	BOLT, SOCKET, 5X16.....	2	90018-Z0H-003	UEBT


4/9

PARTS CATALOGUE NEWS

BOOKNo. : 18VK9604

Block No.	Ref. No.	Part No.	Description	Reqd. QTY UMK 435 T	Base Part No.	Parts catalogue code
	25		TUBE A, FUEL.....	(0)	17703-Z6K-801	UEBT
	26		CLIP, TUBE.....	(0)	91401-ZM3-003	UEBT
	27	16865-Z6J-010	PROTECTOR, TUBE.....	1		UEBT
	28	17701-Z0Z-801	TUBE COMP., FUEL FEED.....	1		UEBT
E-27	2	90015-Z3E-900	BOLT, TOP COVER.....	1	90015-Z0H-003	UEBT
E-28	4	87601-Z0H-J40	MARK, TYPE (GY3).....	1	87601-Z0H-J30	UEBT

F-2-1 GEAR CASE (2)



F-2-1	8		BOLT, SOCKET, 5X20.....	0	90101-VK9-L01	UEBT
	14	90104-VK9-L01	BOLT, HEX., 6X20.....	2	92201-06020-0A	UEBT
	15	90105-VK9-L01	WASHER, PLAIN, 6MM.....	4	94101-06000	UEBT
	24	76243-VL5-G41	SHEET, DEFLECTOR.....	1		UEBT
	25	90103-VL5-G41	BOLT, SOCKET, 5X20.....	4		UEBT


F-3	FRAME
-----	-------

6/9

BOOKNo. : 18VK9604

Block No.	Ref. No.	Part No.	Description	Reqd. QTY	Base Part No.	Parts catalogue code
				UMK 435 T		

F-4-1 BLADE (2)



VK98F0401B


F-4-1	10	72534-VL5-G41	COVER, BLADE.....	1	UEBT	
-------	----	---------------	-------------------	---	------	--

PARTS CATALOGUE NEWS

BOOKNo. : 18VK9604

Block No.	Ref. No.	Part No.	Description	Reqd. QTY UMK 435 T	Base Part No.	Parts catalogue code
-----------	----------	----------	-------------	------------------------------	---------------	----------------------

F-28 LABEL




F-28	1		MARK, CAUTION.....	0	87150-VF9-A00	UEBT
	5	87108-VL6-H30	MARK, PTO INDICATION.....	1		UEBT
	6	87150-VL5-G40	MARK, CAUTION.....	1		UEBT
	7	87641-VL5-G40	MARK, BLADE CAUTION.....	1		UEBT
F-29	5	89211-KWW-601	SPANNER, 8X10 (ATC).....	1	89226-KW7-900	UEBT

BOOKNo. : 18VK9604

Block No.	Ref. No.	Part No.	Description	Reqd. QTY UMK 435 T	Base Part No.	Parts catalogue code
-----------	----------	----------	-------------	------------------------------	---------------	----------------------

F-40 SHOULDER BELT



VK98F4000B

F-40	2		BELT ASSY., SHOULDER.	0	68150-VK9-A01	UEBT
	4	68150-VP8-H01	BELT ASSY., SHOULDER.	1		UEBT
	5	68152-VP8-003	HOOK.	1		UEBT